

Your Global Automation Partner

**TURCK**

# TBIP-L...-FDIO1-2IOL

## Safety-Block-I/O-Module

User Manual



# Table of Contents

	<b>TBIP-L...-FDIO1-2IOL– Safe I/O Channels .....</b>	<b>10</b>
<b>1</b>	<b>About These Instructions .....</b>	<b>10</b>
1.1	Target groups.....	10
1.2	Explanation of symbols used .....	10
1.3	Additional documents.....	10
1.4	Feedback about these instructions.....	11
<b>2</b>	<b>Notes on the Product .....</b>	<b>11</b>
2.1	Product identification.....	11
2.2	Scope of delivery .....	11
2.3	Turck service.....	11
<b>3</b>	<b>For Your Safety.....</b>	<b>12</b>
3.1	Intended use.....	12
3.1.1	Reasonably foreseeable misuse.....	12
3.2	General safety notes .....	13
3.3	Residual risks (EN ISO 12100:2010) .....	13
3.4	Warranty and liability .....	13
3.5	Directives and standards .....	14
3.5.1	National and international directives and standards .....	14
3.5.2	Cited standards.....	14
3.6	Notes on Ex protection.....	14
3.7	ATEX and IECEx approval requirements for use in Ex area .....	15
<b>4</b>	<b>Product Description .....</b>	<b>16</b>
4.1	Device overview .....	16
4.1.1	Type label.....	17
4.2	Properties and features.....	17
4.2.1	Switches and connectors.....	18
4.3	Functions and operating modes .....	19
4.3.1	Safety function.....	19
4.3.2	Safety inputs (FDI).....	19
4.3.3	Safety outputs (FDO) .....	20
4.3.4	Universal standard I/Os.....	20
4.3.5	IO-Link master channels.....	20
4.3.6	Configuration memory .....	20
<b>5</b>	<b>Installing.....</b>	<b>21</b>
5.1	Installing the device in Zone 2 and Zone 22 .....	21
5.2	Mounting onto a mounting plate .....	22
5.3	Grounding the device.....	22
5.3.1	Equivalent wiring diagram and shielding concept .....	22
5.3.2	Shielding of the fieldbus and I/O level .....	23
5.3.3	Grounding the device – I/O level and fieldbus level.....	24
<b>6</b>	<b>Connecting .....</b>	<b>26</b>
6.1	Connecting the device in Zone 2 and Zone 22 .....	26
6.2	Connecting the M12 connectors .....	27
6.3	Connecting the device to Ethernet.....	28

6.4	<b>Connecting the power supply</b> .....	29
6.4.1	24 V supply (SELV/PELV) .....	31
6.5	<b>Connecting safe sensors and actuators</b> .....	32
6.6	<b>Switching examples</b> .....	34
6.6.1	Inputs.....	34
6.6.2	Outputs.....	35
7	<b>Commissioning</b> .....	36
7.1	<b>Initial commissioning</b> .....	36
7.1.1	Mounting and electrical installation .....	36
7.1.2	Configuring in Turck Safety Configurator .....	36
7.1.3	Commissioning the device at the PLC.....	36
7.2	<b>Safety planning</b> .....	36
7.2.1	Prerequisites .....	36
7.2.2	Reaction time .....	37
7.2.3	Safety characteristic data.....	37
7.3	<b>Addressing the device</b> .....	38
7.3.1	Setting the IP Address via rotary coding switches.....	38
7.3.2	Setting the IP Address via the Web Server .....	40
8	<b>Configuring</b> .....	41
8.1	<b>Installing Turck Safety Configurator</b> .....	41
8.2	<b>Licensing Turck Safety Configurator</b> .....	41
8.3	<b>Creating a configuration with the TSC Commissioning wizard</b> .....	41
8.3.1	Selecting a master and creating a basic configuration .....	41
8.3.2	Adapting the configuration of the safe channels .....	45
8.4	<b>Loading the configuration with the TSC commissioning wizard</b> .....	51
8.5	<b>Application example – configuring a safety function in TSC</b> .....	56
8.5.1	Checking and loading the configuration .....	61
8.6	<b>Configuring single channel safety sensors</b> .....	61
8.7	<b>Configuring the device at EtherNet/IP in Rockwell Studio 5000</b> .....	64
8.7.1	Used Hardware .....	64
8.7.2	Used Software .....	64
8.7.3	Creating a new project in Studio 5000.....	65
8.7.4	Opening the catalog file.....	67
8.7.5	Configuring the device in Logix Designer .....	69
9	<b>Operating</b> .....	81
9.1	<b>LED displays</b> .....	81
9.2	<b>Status- and control word</b> .....	83
9.3	<b>Process input data</b> .....	84
9.3.1	Overview – complete module.....	84
9.3.2	Process input data – safe I/O channels .....	85
9.4	<b>Process output data</b> .....	88
9.4.1	Overview – complete module.....	88
9.4.2	Process output data – safe I/O channels .....	88
9.5	<b>Using the configuration memory</b> .....	90
9.5.1	Storing a configuration.....	90
9.5.2	Loading a configuration from the memory chip.....	90
9.5.3	Deleting the memory chip (Erase Memory) .....	90
9.5.4	Configuration transfer and module behavior .....	91

<b>10</b>	<b>Restarting after Device Exchange or Modification .....</b>	<b>93</b>
10.1	Changing a device.....	93
10.1.1	Prerequisites for device replacement.....	93
10.1.2	Procedure for device replacement.....	93
<b>11</b>	<b>Maintenance.....</b>	<b>94</b>
<b>12</b>	<b>Decommissioning.....</b>	<b>94</b>
<b>13</b>	<b>Disposal .....</b>	<b>94</b>
<b>14</b>	<b>Technical Data.....</b>	<b>95</b>
14.1	General technical data.....	95
14.2	Technical data – safety inputs.....	96
14.3	Technical data – safety outputs.....	97
	<b>TBIP-L...-FDIO1-2IOL – Standard DXP Channels .....</b>	<b>99</b>
<b>15</b>	<b>Description of the Standard DXP Channels.....</b>	<b>99</b>
15.1	Functions and operating modes .....	100
15.1.1	DXP channel supply .....	100
<b>16</b>	<b>Connecting .....</b>	<b>101</b>
16.1	Connecting the device in Zone 2 and Zone 22 .....	101
16.2	Connecting digital sensors and actuators.....	101
<b>17</b>	<b>Configuring.....</b>	<b>102</b>
17.1	Parameters.....	102
<b>18</b>	<b>Operating .....</b>	<b>102</b>
18.1	LED displays – DXP channels.....	102
18.2	Process input data.....	103
18.2.1	Overview – complete module.....	103
18.2.2	Process input data – standard DXP channels .....	103
18.3	Process output data .....	104
18.3.1	Overview – complete module.....	104
18.3.2	Process_output_data – standard DXP channels .....	104
<b>19</b>	<b>Technical Data – DXP Channels .....</b>	<b>105</b>
	<b>TBIP-L...-FDIO1-2IOL – Standard IO-Link Channels .....</b>	<b>107</b>
<b>20</b>	<b>Description of the IO-Link Channels .....</b>	<b>107</b>
20.1	Functions and operating modes .....	108
20.1.1	Power supply of the IO-Link ports .....	108
20.1.2	Supply of connected IO-Link devices (Class A and Class B).....	108
<b>21</b>	<b>Connecting .....</b>	<b>109</b>
21.1	Connecting the device in Zone 2 and Zone 22 .....	109
21.2	Connecting IO-Link Devices .....	110
<b>22</b>	<b>Commissioning .....</b>	<b>112</b>
22.1	Commissioning an IO-Link device with IO-Link V1.0.....	112
22.2	Commissioning an IO-Link device with IO-Link V1.1.....	113
<b>23</b>	<b>Configuring.....</b>	<b>115</b>
23.1	Parameters.....	115
23.1.1	Adapting process data mapping.....	119

<b>24</b>	<b>Operating</b>	<b>120</b>
24.1	<b>LED displays – IO-Link channels</b>	<b>120</b>
24.2	<b>Process input data</b>	<b>121</b>
24.2.1	Overview – complete module	121
24.2.2	Process input data – IO Link channels	122
24.3	<b>Process output data</b>	<b>124</b>
24.3.1	Overview – complete module	124
24.3.2	Process output data – IO Link channels	124
24.4	<b>Software diagnostic messages</b>	<b>125</b>
24.5	<b>IO-Link functions for acyclic communication</b>	<b>128</b>
24.5.1	Port functions for Port 0 (IO-Link Master)	128
24.6	<b>Using the data storage mode</b>	<b>134</b>
24.6.1	Parameter "Data storage mode" = activated	134
24.6.2	Parameter "Data storage mode" = read in	135
24.6.3	Parameter "Data storage mode" = overwrite	136
24.6.4	Parameter "Data storage mode" = deactivated, clear	136
<b>25</b>	<b>Troubleshooting</b>	<b>137</b>
25.1	<b>Eliminating parameterization errors</b>	<b>137</b>
<b>26</b>	<b>Technical Data – IO-Link Channels</b>	<b>138</b>
<b>27</b>	<b>Appendix: Approvals and Markings</b>	<b>139</b>
<b>28</b>	<b>Turck Subsidiaries - Contact Information</b>	<b>140</b>

# TBIP-L...-FDIO1-2IOL– Safe I/O Channels

<b>1</b>	<b>About These Instructions .....</b>	<b>10</b>
1.1	Target groups .....	10
1.2	Explanation of symbols used.....	10
1.3	Additional documents .....	10
1.4	Feedback about these instructions .....	11
<b>2</b>	<b>Notes on the Product .....</b>	<b>11</b>
2.1	Product identification .....	11
2.2	Scope of delivery.....	11
2.3	Turck service .....	11
<b>3</b>	<b>For Your Safety .....</b>	<b>12</b>
3.1	Intended use.....	12
3.1.1	Reasonably foreseeable misuse.....	12
3.2	General safety notes.....	13
3.3	Residual risks (EN ISO 12100:2010) .....	13
3.4	Warranty and liability .....	13
3.5	Directives and standards.....	14
3.5.1	National and international directives and standards .....	14
3.5.2	Cited standards.....	14
3.6	Notes on Ex protection .....	14
3.7	ATEX and IECEx approval requirements for use in Ex area.....	15
<b>4</b>	<b>Product Description.....</b>	<b>16</b>
4.1	Device overview .....	16
4.1.1	Type label.....	17
4.2	Properties and features .....	17
4.2.1	Switches and connectors .....	18
4.3	Functions and operating modes.....	19
4.3.1	Safety function.....	19
4.3.2	Safety inputs (FDI).....	19
4.3.3	Safety outputs (FDO) .....	20
4.3.4	Universal standard I/Os.....	20
4.3.5	IO-Link master channels.....	20
4.3.6	Configuration memory .....	20
<b>5</b>	<b>Installing .....</b>	<b>21</b>
5.1	Installing the device in Zone 2 and Zone 22.....	21
5.2	Mounting onto a mounting plate.....	22
5.3	Grounding the device .....	22
5.3.1	Equivalent wiring diagram and shielding concept .....	22
5.3.2	Shielding of the fieldbus and I/O level.....	23
5.3.3	Grounding the device – I/O level and fieldbus level.....	24
<b>6</b>	<b>Connecting.....</b>	<b>26</b>
6.1	Connecting the device in Zone 2 and Zone 22 .....	26
6.2	Connecting the M12 connectors.....	27
6.3	Connecting the device to Ethernet .....	28

## TBIP-L...-FDIO1-2IOL– Safe I/O Channels

6.4	<b>Connecting the power supply</b> .....	29
6.4.1	24 V supply (SELV/PELV).....	31
6.5	<b>Connecting safe sensors and actuators</b> .....	32
6.6	<b>Switching examples</b> .....	34
6.6.1	Inputs .....	34
6.6.2	Outputs.....	35
7	<b>Commissioning</b> .....	36
7.1	<b>Initial commissioning</b> .....	36
7.1.1	Mounting and electrical installation.....	36
7.1.2	Configuring in Turck Safety Configurator .....	36
7.1.3	Commissioning the device at the PLC .....	36
7.2	<b>Safety planning</b> .....	36
7.2.1	Prerequisites .....	36
7.2.2	Reaction time .....	37
7.2.3	Safety characteristic data.....	37
7.3	<b>Addressing the device</b> .....	38
7.3.1	Setting the IP Address via rotary coding switches.....	38
7.3.2	Setting the IP Address via the Web Server .....	40
8	<b>Configuring</b> .....	41
8.1	<b>Installing Turck Safety Configurator</b> .....	41
8.2	<b>Licensing Turck Safety Configurator</b> .....	41
8.3	<b>Creating a configuration with the TSC Commissioning wizard</b> .....	41
8.3.1	Selecting a master and creating a basic configuration.....	41
8.3.2	Adapting the configuration of the safe channels .....	45
8.4	<b>Loading the configuration with the TSC commissioning wizard</b> .....	51
8.5	<b>Application example – configuring a safety function in TSC</b> .....	56
8.5.1	Checking and loading the configuration .....	61
8.6	<b>Configuring single channel safety sensors</b> .....	61
8.7	<b>Configuring the device at EtherNet/IP in Rockwell Studio 5000</b> .....	64
8.7.1	Used Hardware .....	64
8.7.2	Used Software .....	64
8.7.3	Creating a new project in Studio 5000.....	65
8.7.4	Opening the catalog file.....	67
8.7.5	Configuring the device in Logix Designer .....	69
9	<b>Operating</b> .....	81
9.1	<b>LED displays</b> .....	81
9.2	<b>Status- and control word</b> .....	83
9.3	<b>Process input data</b> .....	84
9.3.1	Overview – complete module.....	84
9.3.2	Process input data – safe I/O channels .....	85
9.4	<b>Process output data</b> .....	88
9.4.1	Overview – complete module.....	88
9.4.2	Process output data – safe I/O channels .....	88



## TBIP-L...-FDIO1-2IOL– Safe I/O Channels

9.5	<b>Using the configuration memory</b> .....	90
9.5.1	Storing a configuration.....	90
9.5.2	Loading a configuration from the memory chip.....	90
9.5.3	Deleting the memory chip (Erase Memory) .....	90
9.5.4	Configuration transfer and module behavior .....	91
10	<b>Restarting after Device Exchange or Modification</b> .....	93
10.1	<b>Changing a device</b> .....	93
10.1.1	Prerequisites for device replacement.....	93
10.1.2	Procedure for device replacement.....	93
11	<b>Maintenance</b> .....	94
12	<b>Decommissioning</b> .....	94
13	<b>Disposal</b> .....	94
14	<b>Technical Data</b> .....	95
14.1	<b>General technical data</b> .....	95
14.2	<b>Technical data – safety inputs</b> .....	96
14.3	<b>Technical data – safety outputs</b> .....	97

# 1 About These Instructions

These operating instructions describe the structure, functions and the use of the product and will help you to operate the product as intended. These instructions contain rules for the use of the devices in Safety Instrumented Systems (SIS). The assessment of the safety related values is based on IEC 61508, ISO 13849-1 and IEC 62061.

Read these instructions carefully before using the product. This is to avoid possible damage to persons, property or the device. Retain the instructions for future use during the service life of the product. If the product is passed on, pass on these instructions as well.

## 1.1 Target groups

These instructions are directed to qualified personnel or technically trained personnel (planer, developer, design engineer, installer, electrical specialist, operator, maintenance personnel etc.) and must be carefully read by anyone anyone who assembles, commissions, operates, maintains, dismantles or disposes of the device.

When operating the device in a hazardous area, the user must have a working knowledge of explosion protection (EN 60079-14, etc.).

## 1.2 Explanation of symbols used

The following symbols are used in these instructions:



### **DANGER**

DANGER indicates a dangerous situation with high risk of death or severe injury if not avoided.



### **WARNING**

WARNING indicates a dangerous situation with medium risk of death or severe injury if not avoided.



### **CAUTION**

CAUTION indicates a dangerous situation of medium risk which may result in minor or moderate injury if not avoided.



### **NOTICE**

NOTICE indicates a situation which may lead to property damage if not avoided.



### **NOTE**

NOTE indicates tips, recommendations and useful information on specific actions and facts. The notes simplify your work and help you to avoid additional work.



### **CALL TO ACTION**

This symbol denotes actions that the user must carry out.



### **RESULTS OF ACTION**

This symbol denotes relevant results of actions.

## 1.3 Additional documents

The following additional documents are available online at [www.turck.com](http://www.turck.com):

- Data sheet
- EU Declaration of Conformity (current version)
- Safety Manual
- Approvals

## 1.4 Feedback about these instructions

We make every effort to ensure that these instructions are as informative and as clear as possible. If you have any suggestions for improving the design or if some information is missing in the document, please send your suggestions to [techdoc@turck.com](mailto:techdoc@turck.com).

# 2 Notes on the Product

## 2.1 Product identification

These instructions apply for the following Safety safety module with CIP Safety:

- TBIP-L4-FDIO1-2IOL
- TBIP-L5-FDIO1-2IOL
- TBIP-LL-FDIO1-2IOL

## 2.2 Scope of delivery

The scope of delivery includes:

- TBIP-L...-FDIO1-2IOL
- M12 closure caps
- 7/8" blind caps (not suitable to guarantee IP67/IP69K)

## 2.3 Turck service

Turck supports you with your projects, from initial analysis to the commissioning of your application. The Turck product database under [www.turck.com](http://www.turck.com) contains software tools for programming, configuration or commissioning, data sheets and CAD files in numerous export formats.

The contact details of Turck subsidiaries worldwide can be found on p. [▶ 140].

## 3 For Your Safety

The product is designed according to state-of-the-art technology. However, residual risks still exist. Observe the following warnings and safety notices to prevent damage to persons and property. Turck accepts no liability for damage caused by failure to observe these warning and safety notices.

### 3.1 Intended use

These devices are designed solely for use in industrial areas.

TBIP-L...-FDIO1-2IOL is a decentralized safety module for CIP Safety. The module collects field signals and forwards them safely to a CIP Safety master. Due to the temperature range from -40...+70 °C and IP67/IP69K protection, the module can be used directly on the machine demanding industrial environments.

The module serves for controlling signal devices as for example emergency stop buttons, position switches or OSSDs which are used to ensure human, material or machine protection.

For non-safety relevant functions, the Safety-Hybrid-Modul has additional universal input channels as well as two IO-Link master channels for the connection of IO-Link sensors and IO-Link hubs for expansion to up to 32 I/O signals.

TBIP-L...-FDIO1-2IOL can be used in the following applications:

- Applications up to SIL 3 (according to IEC 61508)
- Applications up to SIL CL3 (according to EN 62061)
- Applications up to Categorie 4 and Performance Level e (according to EN ISO 13849-1)

The devices may only be used as described in these instructions. Any other use is not in accordance with the intended use. Turck accepts no liability for any resulting damage.

#### 3.1.1 Reasonably foreseeable misuse

The device is not suitable for:

- Outdoor use
- The permanent use in liquids

#### Modifications to the device

It is not permitted to modify the technical function or the construction of the device.

### 3.2 General safety notes

- The device may only be assembled, installed, operated, parameterized and maintained by professionally-trained personnel.
- The device may only be used in accordance with applicable national and international regulations, standards and laws.
- The device only meets the EMC requirements for industrial areas and is not suitable for use in residential areas.
- The Performance Level as well as the safety category according to EN ISO 13849-1 depend on the external wiring, the application, the choice of the control devices as well as their arrangement on the machine.
- The user has to execute a risk assessment according to EN ISO 12100:2010.
- Based on the risk assessment a validation of the complete plant/machine has to be done in accordance with the relevant standards.
- Operating the device beyond the specification can lead to malfunctions or to the destruction of the device. The installation instructions must be observed.
- For trouble-free operation, the device must be properly transported, stored, installed and mounted.
- For the release of safety circuits in accordance with EN/IEC 60204-1, EN ISO/ISO 13850 only use the output circuits of connectors C2, C3, C4, C5 and C7 or respectively X2, X3, X4, X5 and X7.
- For connecting sensors and actuators in safety related applications only use the connectors C0...C3 or X0...X3.
- Change the default password of the integrated web server after the first login. Turck recommends using a secure password.

### 3.3 Residual risks (EN ISO 12100:2010)

The wiring proposals described in the following have been tested under operational conditions with the greatest care. Together with the connected periphery of safety related equipment and switching devices they fulfill relevant standards.

Residual risks remain, if

- the proposed wiring concept is changed and connected safety related devices or protective devices are possibly not or insufficiently included in the safety circuit.
- the operator does not observe the relevant safety regulations specified for the operation, adjustment and maintenance of the machine. Here, the inspection and maintenance intervals for the machine should be strictly observed.

Failure to follow these instructions can result in serious injury or equipment damage.

### 3.4 Warranty and liability

Any warranty and liability is excluded for:

- Improper application or not intended use of the product
- Non-observance of the user manual
- Mounting, installation, configuration or commissioning by unqualified persons

### 3.5 Directives and standards

Manufacturers and operators of machines and plants in which the device is used are responsible for observing all relevant directives and standards.

#### 3.5.1 National and international directives and standards

The following guidelines and regulations must be observed:

- 2006/42/EG (machine directive)
- 2014/30/EU (electromagnetic compatibility)
- 2014/34/EU (ATEX directive)
- 2011/65/EU (RoHS directive)
- 89/655/EEG (work equipment directive)
- Accident prevention regulation
- Safety rules and safety regulations according to the actual state of the art

#### 3.5.2 Cited standards

Standard	Title
DIN EN ISO 13849-1:2016-06	Safety-related parts of control systems
EN 62061:2005 + Cor.:2010 + A1:2013 + A2:2015 IEC 62061:2005 + A1:2012 + A2:2015	Safety of machinery - Functional safety of safety-related electrical, electronic and programmable electronic control systems
DIN EN 61508:2011 IEC 61508:2010	Functional safety of electrical/electronic/programmable electronic safety-related systems
DIN EN 61131-2:2008 IEC 61131-2:2007	Programmable controllers
EN ISO 12100:2010 DIN EN ISO 12100:211-03	Safety of machinery - General principles for design - Risk assessment and risk reduction

### 3.6 Notes on Ex protection

- When using the device in explosion-protection circuits, the user must have a working knowledge of explosion protection (EN 60079-14 etc.).
- Observe national and international regulations for explosion protection.
- Use the device only within the permissible operating and ambient conditions (see approval data and Ex approval specifications).

### 3.7 ATEX and IECEx approval requirements for use in Ex area

- Only use the device in an area with no more than pollution degree 2.
- Only disconnect and connect circuits when no voltage is applied.
- Only operate the switches if no voltage is present.
- Connect the metal protective cover to the equipotential bonding in the Ex area.
- Ensure impact resistance in accordance with EN IEC 60079-0 – alternative measures:
  - Install the device in the TB-SG-L protective housing (available in the set with Ultem window: ID 100014865) and replace the service window with an Ultem window.
  - Install the device in an area offering impact protection (e.g. in robot arm) and attach a warning: "DANGER: Only connect and disconnect circuits when no voltage is present. Do not operate switches when energized."
- Do not install the device in areas critically exposed to UV light.
- Prevent risks caused by electrostatic charge.
- Protect unused connectors with dummy plugs to ensure protection class IP67.

## 4 Product Description

The TBIP-L...-FDIO1-2IOL is a hybrid safety block I/O module for CIP Safety via EtherNet/IP. The device has two 2-channel digital safety inputs (FDI) for the connection of different safety sensors as for example light barriers or emergency stop buttons. Two further safety channels (FDX) can be freely used as inputs (FDI) or outputs (FDO).

The configuration of the safe I/Os and their function is realized by means of a software tool the Turck Safety Configurator.

Non-safety related signals can be connected to the four universal digital inputs/outputs of the device. The device also has two IO-Link masters. In combination with Turck I/O hubs, up to 32 I/Os can be connected. Both the standard and the IO-Link channels of the TBIP-L...-FDIO1-2IOL can be safely switched off internally.

### 4.1 Device overview




Fig. 1: TBIP-L4-FDIO1-2IOL




Fig. 2: TBIP-L5-FDIO1-2IOL






Fig. 3: TBIP-LL-FDIO1-2IOL

### 4.1.1 Type label

#### TBIP-L4-FDIO1-2IOL

Ident-No.: 100000360 Hans Turck GmbH & Co. KG  
 HW: D-45466 Mülheim a. d. Ruhr  
 Charge code: www.turck.com  
 YoC: Made in Germany

Fig. 4: Type label TBIP-L4-FDIO1-2IOL

#### TBIP-L5-FDIO1-2IOL

Ident-No.: 6814056 Hans Turck GmbH & Co. KG  
 HW: D-45466 Mülheim a. d. Ruhr  
 Charge code: www.turck.com  
 YoC: Made in Germany

Fig. 5: Type label TBIP-L5-FDIO1-2IOL

#### TBIP-LL-FDIO1-2IOL

Ident-No.: 100027260 Hans Turck GmbH & Co. KG  
 HW: D-45466 Mülheim a. d. Ruhr  
 Charge code: www.turck.com  
 YoC: Made in Germany


Fig. 6: Type label TBIP-LL-FDIO1-2IOL

## 4.2 Properties and features


- Two safety-related SIL3 inputs FDI
- Two safety-related SIL3 In-/outputs FDX
- Four non-safety in-/outputs DXP
- Two IO-Link master ports (IOL)
- Safe shutdown of the standard channels and one I/O-Link channel
- Safe PP/PM-switching of the actuator power supply
- Up to 2 A per output
- Usable in SIL CL3 according to EN 62061 or PLe according to DIN EN ISO 13849-1
- 7/8" power supply connectors:  
TBIP-L4-FDIO1-2IOL and TBIP-L4-FDIO1-2IOL
- M12 power supply connector, L coded:  
TBIP-LL-FDIO1-2IOL
- Two 4-pin M12-connectors for Ethernet
- Multiple LEDs for status indication
- Integrated Ethernet switch, allows line topology
- Integrated web server
- Transmission rate 10 Mbps and 100 Mbps
- Fiberglass reinforced housing
- Shock and vibration tested
- Fully potted module electronics
- Protection class IP65/IP67/IP69K

4.2.1 Switches and connectors

TBIP-L...-FDIO1-2IOL

	Designation	Meaning
	X1	Power IN
	X2	Power OUT
	C0	FDI0/1, safety-related input
	C1	FDI2/3, safety-related input
	C2	FDX4/5, safety-related input
	C3	FDX6/7, safety-related input
	C4	DXP8/9, standard in-/outputs (safe shutdown via FSO0 possible)
	C5	DXP10/11, standard in-/outputs (safe shutdown via FSO0 possible)
	C6	IOL, IO-Link port 1
	C7	IOL, IO-Link port 2 (safe shutdown via FSO 1 possible)
	IP Address	Rotary coding switch for address setting (last byte of the IP address for the safe function unit)
	P1	Ethernet 1
	P2	Ethernet 2
	FE	Functional earth

TBIP-LL-FDIO1-2IOL

	Designation	Meaning
	XD1	Power IN
	XD2	Power OUT
	X0	FDI0/1, safety-related input
	X1	FDI2/3, safety-related input
	X2	FDX4/5, safety-related input
	X3	FDX6/7, safety-related input
	X4	DXP8/9, standard in-/outputs (safe shutdown via FSO0 possible)
	X5	DXP10/11, standard in-/outputs (safe shutdown via FSO0 possible)
	X6	IOL, IO-Link port 1
	X7	IOL, IO-Link port 2 (safe shutdown via FSO 1 possible)
	IP Address	Rotary coding switch for address setting (last byte of the IP address for the safe function unit)
	XF1	Ethernet 1
	XF2	Ethernet 2
	FE	Functional earth

## 4.3 Functions and operating modes

### 4.3.1 Safety function

The TBIP-L...-FDIO1-2IOL provides two safe digital SIL3 inputs (FDI) and two SIL3-connectors (FDX), configurable as in- or outputs.

The following devices can be connected to the safety inputs:

- 1- and 2-channel safety switches and sensors
- Contact based switches, e.g. emergency switches, protective door switches
- Sensors with OSSD switching outputs
- Antivalently switching OSSD sensors

The two safe SIL3 outputs can be used PP- or PM-switching.

#### Safe Status

In the safe state the device outputs are in LOW-state (0). The inputs report a LOW-state (0) to the logic.

#### Fatal Error

- Incorrect wiring at the output (i.e. capacitive load, energetic recovery)
- Short-circuit at the line control output T2
- Incorrect power supply
- Strong EMC disturbances
- Internal device error

### 4.3.2 Safety inputs (FDI)

The safe inputs are suitable for the connection of safety-related sensors:

- Max. four 2-channel safety switches and sensors
- Contact based switches, e.g. emergency switches, protective door switches
- Sensors with OSSD switch outputs with test pulses
- Sensors with OSSD switch outputs without test pulses

#### Error detection and diagnostics

##### Internal:

- Device self test: Diagnosis of internal device errors

##### External:

- Cross connection diagnosis: The device detects a cross connection between the sensor supplies at the inputs or between one sensor supply to another potential (if the test pulses are activated)
- Discrepancy diagnosis: for 2-channel inputs
- Short-circuit diagnosis

#### Parameters

For each input the following types can be selected:

- Safe input for potential free contacts (NC/NC)
- Safe antivalent input for potential-free contacts (NC/NO)
- Safe electronic input at OSSD-output with test pulses

### 4.3.3 Safety outputs (FDO)

The safe SIL3 outputs can be used PP- or PM-switching.

- Max. two 2-channel safety output (outputs are supplied via V1)

#### Error detection and diagnostics

##### **Internal:**

- Device self test: Diagnosis if an output can not change to the safe state due to an internal error.

##### **External:**

- Overload diagnosis
- Cross connection diagnosis
- Short-circuit diagnosis

#### Parameters

- Safe output PP-switching:  
Safe output, the load is connected between P-terminal and Ground-terminal.
- Safe output PM-switching:  
Safe output, the load is connected between P-terminal and M-terminal (mass), necessary for special loads which need a separation from Ground.

### 4.3.4 Universal standard I/Os

The function description of the non safe universal I/Os can be found in the second part of these instructions :

**TBIP-L...-FDIO1-2IOL – Standard I/O channels** [▶ 99]

### 4.3.5 IO-Link master channels

The function description of the non safe IO-Link master channels can be found in the third part of these instructions:

**TBIP-L...-FDIO1-2IOL – Standard IO-Link master channels** [▶ 107]

### 4.3.6 Configuration memory

A pluggable memory stick is included in the scope of delivery of TBIP-L...-FDIO1-2IOL. It serves for storing the safety function configured via Turck Safety Configurator. It allows to transfer the configuration of one device to another device, e. g. for device exchange.

## 5 Installing

### 5.1 Installing the device in Zone 2 and Zone 22

In Zone 2 and Zone 22, the devices can be used in conjunction with the protective housing set TB-SG-L (ID 100014865).



#### **DANGER**

Potentially explosive atmosphere

**Risk of explosion through spark ignition**

**For use in Zone 2 and Zone 22:**

- ▶ Only install the device if there is no potentially explosive atmosphere present.
- ▶ Observe requirements for Ex approval.

- ▶ Unscrew the housing. Use Torx T8 screwdriver.
- ▶ Replace the service window with the enclosed Ultem window.
- ▶ Place the device on the base plate of the protective housing and fasten both together on the mounting plate, see [▶ 22].
- ▶ Connect the device, see [▶ 26].
- ▶ Mount and screw the housing cover according to the following figure. The tightening torque for the Torx T8 screw is 0.5 Nm.




Fig. 7: Mounting the device in protection housing TB-SG-L

## 5.2 Mounting onto a mounting plate



### NOTICE

Mounting on uneven surfaces

#### Device damage due to stresses in the housing

- ▶ Fix the device on a flat mounting surface.
- ▶ Use two M6 screws to mount the device.

The device can be screwed onto a flat mounting plate.

- ▶ Attach the module to the mounting surface with two M6 screws. The maximum tightening torque for the screws is 1.5 Nm.
- ▶ Avoid mechanical stresses.
- ▶ Optional: Ground the device.




Fig. 8: Mounting the device onto a mounting plate

## 5.3 Grounding the device

### 5.3.1 Equivalent wiring diagram and shielding concept




Fig. 9: Equivalent wiring diagram and shielding concept – TBIP-L4-FDIO1-2IOL




Fig. 10: Equivalent wiring diagram and shielding concept – TBIP-L5-FDIO1-2IOL




Fig. 11: Equivalent wiring diagram and shielding concept – TBIP-LL-FDIO1-2IOL

### 5.3.2 Shielding of the fieldbus and I/O level

The fieldbus and the I/O level of the modules can be grounded separately.




Fig. 12: Grounding clip (1), grounding ring (2) and metal screw (3)

The grounding ring (2) is the module grounding. The shielding of the I/O level is permanently connected to the module grounding. The module grounding is only connected to the reference potential of the installation when the module is mounted.

### Shielding concept of the I/O modules (I/O level)

In the case of direct mounting on a mounting plate, the module grounding is connected to the reference potential of the system via the metal screw in the lower mounting hole (3). If module grounding is not desired, the electrical connection to the reference potential must be interrupted, e.g. by using a plastic screw.

### Shielding concept of the fieldbus level

On delivery, a grounding clip is provided on the connectors for the fieldbus connection.

When mounted directly on a mounting plate, the shielding of the fieldbus cables is routed directly to the module ground via the grounding clip and the metal screw in the lower mounting hole.

If direct grounding of the fieldbus shield is not desired, the grounding clip must be removed. In this case, the fieldbus shield is connected to the module ground via an RC element.

#### 5.3.3 Grounding the device – I/O level and fieldbus level

The grounding of the fieldbus level can either be connected directly via the grounding clip (1) or connected and routed indirectly via an RC element to the grounding of the I/O level. If the grounding is to be routed via an RC element, the grounding clip must be removed.




Fig. 13: Grounding clamp (1)



Removing the grounding clip: disconnect the direct grounding of the fieldbus level

- ▶ Use a flat screwdriver to slide the grounding clamp forward and remove it.




Fig. 14: Use a flat slotted screwdriver to push the grounding clip forwards and remove it.

Mounting the grounding clip: grounding the fieldbus level directly

- ▶ Place the grounding clamp between the fieldbus connectors by using a screwdriver in such way that the clamp contacts the metal housing of the connectors.
- ▶ The shielding of the fieldbus cables is connected to the grounding clip.




Fig. 15: Mounting the grounding clip

Grounding the device – mounting on a mounting plate

- ▶ For mounting onto a mounting plate: Fix the device with an M6 metal screw through the lower mounting hole.
- ⇒ The shielding of the M12 flanges for the I/O level is connected to the reference potential of the installation via the M6 metal screw.
- ⇒ With mounted grounding clip: The shielding of the fieldbus is connected to the reference potential of the installation via the module grounding of the I/O level.

## 6 Connecting



### **WARNING**

Intrusion of liquids or foreign bodies through leaking connections

#### **Danger to life due to failure of the safety function**

- ▶ Tighten M12 connectors with a tightening torque of 0.6 Nm.
  - ▶ Tighten 7/8" connectors with a tightening torque of 0.8 Nm.
  - ▶ Only use accessories that guarantee the protection class.
  - ▶ Close unused M12 connectors with the supplied screw caps. The tightening torque for the screw caps is 0.5 Nm.
  - ▶ Use appropriate 7/8" sealing caps, e.g. type RKMV-CCC. The caps not part of the scope of delivery.
- 

### 6.1 Connecting the device in Zone 2 and Zone 22



### **DANGER**

Potentially explosive atmosphere

#### **Risk of explosion through spark ignition**

#### **When used in Zone 2 and Zone 22:**

- ▶ Only disconnect and connect circuits when no voltage is applied.
  - ▶ Only use connecting cables that are approved for use in potentially explosive atmospheres.
  - ▶ Use all connectors or seal them with blind plugs.
  - ▶ Observe requirements for Ex approval.
-

## 6.2 Connecting the M12 connectors

- ▶ When connecting the cables to the M12-connectors, use the torque screwdriver mentioned below.



Fig. 16: Torque screwdriver

Description	Type	ID
Torque screwdriver, torque range 0.4...1.0 Nm	Torque-Wrench-Set	6936171
■ M8 (SW9)	Turck Line + BUS	
■ M12 for bus cables (SW13)		
■ M12 for sensor cables (SW14)		

### 6.3 Connecting the device to Ethernet

For the connection to Ethernet the device has an integrated auto-crossing switch with two 4-pole, D-coded M12 ×1-Ethernet-connectors. The maximum tightening torque is 0.6 Nm.

TBIP-L4 and TBIP-L5




Fig. 17: M12 Ethernet connector

- ▶ Connect the device to Ethernet according to the pin assignment below.
- ▶ Always seal unused connectors with suitable screw caps or blind caps. The tightening torque for the screw caps is 0.5 Nm.



Fig. 18: Pin assignment Ethernet connectors

TBIP-LL




Fig. 19: M12 Ethernet connector

- ▶ Connect the device to Ethernet according to the pin assignment below.
- ▶ Always seal unused connectors with suitable screw caps or blind caps. The tightening torque for the screw caps is 0.5 Nm.



Fig. 20: Pin assignment Ethernet connectors

## 6.4 Connecting the power supply



**NOTE**

The device is supplied via V1. V2 is only fed through.

### TBIP-L4 and TBIP-L5



**NOTE**

We recommend the use of pre-assembled 5-pin power supply cables, Turck type 52 (e.g. RKM52-1-RSM52). Suitable cables can be found on [www.turck.com](http://www.turck.com).

For the connection to the power supply, the device has two 5-pin 7/8" connectors. The power supply connectors are designed as 4-pin (TBIP-L4) or 5-pin (TBIP-L5) connectors. V1 and V2 are galvanically isolated. The maximum tightening torque is 0.8 Nm.




Fig. 21: TBIP-L4... – 7/8" connector for connecting the supply voltage




Fig. 22: TBIP-L5... – 7/8" connector for connecting the supply voltage

- ▶ Connect the device to the power supply according to the pin assignment shown below.



Fig. 23: TBIP-L4... – pin assignment power supply connectors




Fig. 24: TBIP-L5... – pin assignment power supply connectors

Connector	Function
X1	Power feed
X2	Continuation of the power to the next node

Voltage	Function
V1	System voltage: power supply 1 (incl. supply of electronics)
V2	Load voltage: power supply 2, fed through, not used in device

TBIP-LL



**NOTE**

We recommend the use of pre-assembled 5-pin power supply cables e.g. RK-P56PLB-1-RSP56PLB/TXG (not suitable for Ex use). Suitable cables can be found on [www.turck.com](http://www.turck.com).

For the connection to the power supply, the device has two 5-pin, L coded M12 connectors. V1 and V2 are galvanically isolated. The maximum tightening torque is 0.6 Nm.




Fig. 25: M12 connector for connecting the supply voltage

- ▶ Connect the device to the power supply according to the pin assignment shown below.
- ▶ Always seal unused connectors with suitable screw caps or blind caps. The tightening torque for the screw caps is 0.5 Nm.




Fig. 26: Pin assignment power supply connectors

Connector	Function
XD1	Power feed
XD2	Continuation of the power to the next node

Voltage	Function
V1	System voltage: power supply 1 (incl. supply of electronics)
V2	Load voltage: power supply 2, fed through, not used in device

## 6.4.1 24 V supply (SELV/PELV)



### **WARNING**

Incorrect or defective power supply unit

#### **Danger to life due to dangerous voltages on touchable parts**

- ▶ Only use SELV or PELV power supplies in accordance with EN ISO 13849-2, which allow a maximum of 60 VDC or 25 VAC in the event of a fault.
- 

### External supply of sensors and actuators

Sensors and actuators with external power supply can also be connected to the device. The use of SELV or PELV power supplies must also be guaranteed for externally supplied sensors and actuators.

### Decoupling of external electrical circuits

Decouple circuits that are not designed as SELV or PELV systems by means of optocouplers, or other measures.



### **WARNING**

Potential differences

#### **Dangerous additions of voltages**

- ▶ Avoid potential differences between internal and external load voltage supplies (24 VDC).
-

## 6.5 Connecting safe sensors and actuators



### NOTE

We recommend pre-assembled 5-pin sensor cables. Suitable cables can be found on [www.turck.com](http://www.turck.com).



### DANGER

Wrong supply of sensors and actuators  
**Danger to life due to external supply**

- ▶ Exclude external supply.
- ▶ Guarantee that the inputs are only supplied through the same 24 V source as the device itself.

The device has M12 connectors for connecting safe sensors and actuators. The maximum tightening torque is 0.6 Nm.

### Safety inputs (FDI)




Fig. 27: M12 connector, safety inputs (FDI)

- ▶ Connect the sensors to the device according to the pin assignment.
- ▶ Always seal unused connectors with suitable screw caps or blind caps. The tightening torque for the screw caps is 0.5 Nm.




Fig. 28: Pin assignment FDI at C0...C1 or X0...X1

Signal	Meaning
VAUX1/T1	Sensor supply/test pulse 1
FDI (T2)	Digital input 2
GND (V1)	Ground V1
FDI (T1)	Digital input 1
T2	Test pulse 2



Safe in- and outputs (FDX)




Fig. 29: M12 connector, safety in-/outputs (FDX)

- ▶ Connect the sensors and actuators to the device according to the pin assignment.
- ▶ Always seal unused connectors with suitable screw caps or blind caps. The tightening torque for the screw caps is 0.5 Nm.




Fig. 30: Pin assignment FDX at C2...C3 or X2...X3

Signal	Meaning
VAUX1/T1	Sensor supply/test pulse 1
FDO-/FDI (T2)	Digital output (M)/digital input 2
GND (V1)	Ground V1
FDO+/FDI (T1)	Digital output (P)/digital input 1
T2	Test pulse 2



**DANGER**


Connection of fast reacting loads  
**Danger to life due to connection failures**

- ▶ Use loads with mechanical or electrical inertia. Positive and negative test pulses have to be tolerated.


## 6.6 Switching examples

### 6.6.1 Inputs

#### Safe equivalent input for potential-free contacts (normally closed/normally closed)




Connected in the switch



Two individual switches switching simultaneously via one application


#### Safe antivalent input for potential-free contacts (normally closed/normally closed)



In the antivalent circuit, switches can be connected in different ways. The decisive factor for enabling is where the normally closed contact is connected.

- Example 1: The LEDs of the inputs are off when not actuated and light up when actuated. Use: e.g. for door monitoring with magnetic reed contacts
- Example 2: The LEDs of the inputs are off when actuated and light up when not actuated. Use: as programming for two-hand switches with two separate contacts

#### Safe electronic input (OSSD)




With this connection and corresponding parameterization, the pulsing of pins 1 and 5 is switched off. The supply voltage at pin 5 remains switched on.

Note:

- ▶ To avoid errors, do not use 5-pin cables to the sensor.

#### Safe electronic input (OSSD) antivalent switching




With this connection and corresponding parameterization, the pulsing of pins 1 and 5 is switched off. The supply voltage at pin 5 remains switched on. The NC contact is connected to pin 2 in order to receive a release when it is actuated. Connection example: Banner STB Touch

Note:

- ▶ To avoid errors, do not use 5-pin cables to the sensor.

**Safe inputs with single-channel mechanical contacts**



Inputs can be queried 1-channel.

- ▶ Connect sensors via two connection cables and a Y-plug (i.e. ID: 6634405) to the M12 sockets of the modules.

Note:

Changes to the preset properties of the inputs directly affect the performance level to be achieved. For more information, see the online help of the Turck Safety Configurator.


6.6.2 Outputs



**NOTE**


Any change in the test pulse interval of the outputs will change the performance level. The software and the online help of the software contain further information.

**Safe output PP-switching**



- ▶ For PP switching outputs, connect the negative pole of the load to the GND-contractor of the respective output (pin 3).
- ▶ Another connection of the negative pole to the GND of the power supply unit is not permitted!
- ▶ The wiring has to allow an exclusion of faults regarding cross connection.

**Safe output PM switching**



- ▶ For PM switching outputs, connect the negative pole of the load to the M connector of the respective output (pin 2).

## 7 Commissioning

### 7.1 Initial commissioning

#### 7.1.1 Mounting and electrical installation

- ▶ Set the IP address at the device [▶ 38].
- ▶ Please assure the proper closing of the protective cover over the rotary coding switches.
- ▶ Mount the device according to the instructions [▶ 21].
- ▶ Connect Ethernet cables according to the instructions [▶ 28].
- ▶ Connect the power supply according to the instructions [▶ 29].
- ▶ Wire the in- and outputs depending on their use [▶ 32], [▶ 34].
- ▶ Seal unused connectors with the respective protection caps [▶ 26].

#### Connecting the supply voltage

- ▶ Before the operating voltage is applied, assure that:
  - no wiring or grounding errors exist
  - a safe grounding of the device/of the application is guaranteed
- ▶ Connecting the supply voltage
- ▶ After the supply voltage is applied, check if all supply voltages as well as the output voltage are in the permitted range.
- ▶ Check if the device works properly or if errors are displayed by controlling the diagnostics an status displays.

#### 7.1.2 Configuring in Turck Safety Configurator

- ▶ Configure the device as described in chapter “Configuring” [▶ 41].

#### 7.1.3 Commissioning the device at the PLC

- ▶ Configure the device in the PLC.
- ▶ Configure the device in the configuration software [▶ 64].
- ▶ Load parameterization and configuration data via the PLC into the device.
- ▶ Execute a functional test.
- ▶ Check if the device works according to the configuration and if all safety functions react as expected.

### 7.2 Safety planning

The operator is responsible for the safety planning.

#### 7.2.1 Prerequisites

- ▶ Perform a hazard and risk analysis.
- ▶ Develop a safety concept for the machine or plant.
- ▶ Calculate the safety integrity for the complete machine or plant.
- ▶ Validate the complete system.

7.2.2 Reaction time

If the device is operated with higher availability, the max. reaction time is extended (see "Safety Characteristic Data").

In addition to the reaction time in the device, reaction times of the further Safety components have to be system considered eventually. Please find the respective information in the technical data of the respective devices.

Further information about the reaction time can be found in the online help for the Turck Safety Configurator.

7.2.3 Safety characteristic data

Characteristic data	Value	Standard
PL (Performance Level)	e	EN/ISO 13849-1:2015
Safety category	4	
MTTF <sub>D</sub>	> 2500 years (high)	
Permissible duration of use (TM)	20 years	
DC	99 %	
SIL (Safety Integrity Level)	3	EN 61508
PFH	$4.1 \times 10^{-6}$	
PFD	$5 \times 10^{-6}$	
Maximum on-time	12 months	
SIL CL	3	EN 62061:2005+
PFH <sub>D</sub>	$5.8 \times 10^{-9}$ 1/h	Cor.:2010+A1:2013+A2:2015
SFF	98.22 %	

Max. reaction time in case of shutdown	Value	Standard
CIP Safety > local output	25 ms	EN 61508
Local input > CIP Safety	20 ms	
Local input <> local output	35 ms	

## 7.3 Addressing the device

The device supports two IP addresses. Whether the secondary IP address is required depends on the application and the CIP Safety Scanner used.

The first three bytes of the Main IP address can be set via the device's web server (IP address in delivery state: 192.168.1.254). The last byte of the IP address Main IP address can either be set via the rotary coding switches at the device, via the Turck Service Tool or via the web server.



### NOTE

Turck recommends setting the IP address via the rotary coding switches (Static Rotary) on the device. The rotary mode supports easy device replacement.

- **Main IP Address:**  
IP address of the device to access the device with Turck Safety Configurator, PLC, web server, Turck Service Tool, etc.
- **Secondary IP Address:**  
depending on application possibly without function, must then be 0.0.0.0



### NOTE

The Secondary IP address can only be set by using the web server of the device.

### 7.3.1 Setting the IP Address via rotary coding switches

- ▶ Open the cover above the switches.
- ▶ Set the last byte of the Main IP address via the three rotary coding switches under the cover at the device.
- ▶ Execute a power cycle.




Fig. 31: Rotary coding switches at the device

In the delivery state, the rotary switches are set to 600 (0 - 0 - 0).

<b>Switch position</b>	<b>Meaning</b>
000	192.168.1.254
1...254	Rotary mode (Static rotary) Sets the last byte of the Main IP address, accept the setting with a device restart
300	BOOTP
400	DHCP
500	PGM
600	PGM-DHCP
900	Factory Reset: Resets device to factory settings
901	Erase Memory: Deletes the content of the memory chip

### 7.3.2 Setting the IP Address via the Web Server

To set the IP address via the web server, the device must be in PGM mode.

- ▶ Open the web server.
- ▶ Log on to the device as administrator. The default password for the web server is “password”.
- ▶ Click **Station** → **Network Configuration**.
- ▶ Change the IP address and, if necessary, the subnet mask and the default gateway.
- ▶ Write the new IP address, the subnet mask and the default gateway via **Submit** into the device.



#### NOTE

The password is transmitted in plain text.



#### NOTICE

Inadequately secured devices

##### Unauthorized access to sensitive data

- ▶ Change password after first login. Turck recommends using a secure password.
- ▶ Adapt the password to the requirements of the network security concept of the system in which the devices are installed.

### Setting the Secondary IP Address via the web server

Depending on the safety scanner used, a second IP address may not be needed. In these cases, the IP address must be set to 0.0.0.0.




Fig. 32: Web server – setting the secondary IP address to 0.0.0.0



## 8 Configuring

### 8.1 Installing Turck Safety Configurator

The Turck Safety Configurator is available for download as zip archive on [www.turck.com](http://www.turck.com).



#### NOTE

A coupon code is required to download the software. The coupon code can be requested from Turck customer service. Further information can be found on the product page of the software.

---

- ▶ Unpack the zip archive and install Turck Safety Configurator.

### 8.2 Licensing Turck Safety Configurator

The licensing is done via coupon code.

- ▶ Enter the coupon code on the Turck homepage following this link: [https://www.turck.de/en/product/SW\\_Turck\\_Safety\\_Configurator](https://www.turck.de/en/product/SW_Turck_Safety_Configurator).
- ▶ If the coupon code is missing, please order a coupon code via E-mail under the following E-mail address: [TM-BWSsoftwareSupport@turck.com](mailto:TM-BWSsoftwareSupport@turck.com)

Software licensing for virtual machines (VM)

- ▶ Enter the coupon code on the Turck homepage following this link: [https://www.turck.de/en/product/SW\\_Turck\\_Safety\\_Configurator](https://www.turck.de/en/product/SW_Turck_Safety_Configurator).
- ▶ If the coupon code is missing, please order a coupon code via E-mail under the following E-mail address: [TM-BWSsoftwareSupport@turck.com](mailto:TM-BWSsoftwareSupport@turck.com)



#### NOTE

The software can only be used on a virtual machine with Internet access.

---

### 8.3 Creating a configuration with the TSC Commissioning wizard

- ▶ Start the software.
- ⇒ Turck Safety Configurator starts with the Start assistant, which will lead through the first steps after program start.

#### 8.3.1 Selecting a master and creating a basic configuration

- ▶ Select the used device in the **Select master** dialog and confirm with **OK**.




Fig. 33: TSC – selecting a master

⇒ The dialog box **Properties – TB...** is opened.




Fig. 34: TSC – hardware configuration

In the register tab **Local I/Os**, the safe slots of the device are configured.

## Basic configuration

In the basic configuration, the safe inputs (FDI) at C0 and C1 are defined as 2-channel forced, safe inputs (dry contact). The two internal safety outputs and the safe in-/outputs (FDX) at C2 and C3 are configured as safe outputs according to PLe.

Channel	Type	I/O name	Device name
FDI0/1	E-stop	Safe input (dry contact)	Double channel forced
FDI2/3	E-stop	Safe input (dry contact)	Double channel forced
FSO0	Safe output	Safe output	Safe output according to PLe (test pulse every 500 ms)
FSO1	Safe output	Safe output	Safe output according to PLe (test pulse every 500 ms)
FDX4/5	Safe output	Safe output	Safe output according to PLe (test pulse every 500 ms)
FDX6/7	Safe output	Safe output	Safe output according to PLe (test pulse every 500 ms)

- ▶ Complete the configuration with **OK**.
- ⇒ The basic configuration is applied.
- ⇒ The release circuits of the basic configuration are automatically created.

Release circuits (OSSDs) of the basic configuration

In the basic configuration, the release circuits OSSD1...OSSD4 and OSSD63 and OSSD64 are predefined as follows:

Release circuit (OSSD)	Channels
OSSD 1	FSO0
OSSD 2	FSO1
OSSD 3	FDX4/5
OSSD 4	FDX6/7
...	...
OSSD 63	FDI2/3
OSSD 64	FDIO/1




Fig. 35: TSC – release circuits (OSSDs) of the basic configuration

8.3.2 Adapting the configuration of the safe channels

The channels of the device are adapted to requirements of the respective application in the register tab **Local I/Os** → **Expert**.

Configuration options




Fig. 36: TSC – configuration of I/Os

Clicking **Expert** opens the expert settings for inputs and outputs.




Fig. 37: TSC – expert settings



**NOTE**

The description of the functions is part of the online help of the Turck Safety Configurator.

**Example configuration**




Fig. 38: TSC – expert settings (example configuration)

Con- nector at device	Channels	Type	I/O type (Expert setting)	Later function (see application ex- ample [ 56])
C0	FDI0/1	E-stop	Safe input (dry contact), double channel forced	Safely switches off output at FDX4/5.
C1	FDI2/3	Light grid (AOPD)	Safe input (OSSD), double channel forced	Safely switches off output at FDX4/5.
-	FSO0	Safe output	Safe output according to PLe (test pulse every 500 ms)	Internal safety outputs The non-safe channels at C4... C7 remain permanently on via the in- ternal safe outputs.
-	FSO1	Safe output	Safe output according to PLe (test pulse every 500 ms)	
C2	FDX4/5	Safe output	Safe output according to PLe (test pulse every 500 ms)	Is safely switched off when output FDX4/5 switches, signal forwarding to the F-CPU
C3	FDX6/7	Safe output, switch-off delay	Safe output (plus and minus switching, no test pulses)	Is safely switched off when output FDX4/5 switches, signal forwarding to the F-CPU
C4...C7		Non-safe channels		

- ▶ Adapt the expert settings and close with **OK**.

## Advanced settings – Global error unlock

If the **Advanced settings** are activated, a fieldbus bit for a global error unlock of the device can be configured in the **Service** register tab.




Fig. 39: TSC – advanced settings, global error unlock

- ▶ Set the global error unlock and close the Properties dialog with **OK**.



### NOTE

The global error unlock can also be executed via the process data bit "UNLK" in the device process output data.



## CIP Safety settings

The CIP Safety tab is used to specify whether the configuration is saved without SCID timestamps, with an automatically generated SCID time stamp, or with a manually defined SCID time stamp.




Fig. 40: TSC – CIP Safety options

Complete the hardware configuration in the start assistant

- ▶ Close the dialog box hardware configuration with **OK**.
- ⇒ The release circuits for the hardware configuration (example configuration) are created.




Fig. 41: TSC – release circuits (example configuration)

Channels	Type	OSSD	Adaptation
FDI0/1	E-stop	64. OSSD	unchanged
FDI2/3	Light grid (AOPD)	63. OSSD	unchanged
FSO0	Safe output	1. OSSD	unchanged
FSO1	Standard input	2. OSSD	unchanged
FDX4/5	Safe output	3. OSSD	The state of OSSD 64 and 63 leads to switch-off this OSSD, monitored (see “Switch off FDX4/5 (1. OSSD)”)
FDX6/7	Safe output, switch-off delay	4. OSSD	The state of OSSD 3 leads to switch-off this (see “Switch off FDX6/7 (4. OSSD)”)

## 8.4 Loading the configuration with the TSC commissioning wizard

- ▶ Start the commissioning wizard and click **Next >**.




Fig. 42: TSC – start the commissioning wizard

- ▶ In the dialog **Commissioning wizard settings**, enter the **Name of the validator** and the **Password for safety monitors** (release password) and confirm with **OK**.




Fig. 43: TSC – Commissioning wizard, assigning a password

⇒ The connected TBIP-L...-FDIO1-2IOL is prepared for the configuration download.




Fig. 44: TSC – commissioning wizard, preparing the master

- ▶ **Optional:** If the TBIP-L...-FDIO1-2IOL is not found, enter the device's IP address under **Ethernet** or search the connected device via the ... button.




Fig. 45: TSC – interface configuration

- ▶ Confirm with OK and store the setting in the project (**store the interface in the workspace**).

- ⇒ The configuration is sent to the TBIP-L...-FDIO1-2IOL. This process may take a few seconds.
- ⇒ The configuration protocol is created.




Fig. 46: TSC – commissioning wizard configuration protocol

- ▶ Check the configuration using the configuration protocol and confirm the check.




Fig. 47: TSC – confirming check of the configuration protocol

- ▶ Release the configuration in the **Validate configuration** dialog box with the data entered before (Name of the validator, Password).




Fig. 48: TSC – release configuration

- ⇒ The configuration has been released.




Fig. 49: TSC – release configuration

- ▶ Click **OK** and complete the commissioning with **Finish**.
- ⇒ The Turck Safety Configurator changes to the online mode and opens the diagnostics configuration.




Fig. 50: TSC – Diagnostics configuration (online, not communication to safety PLC)

## 8.5 Application example – configuring a safety function in TSC

The following safety function is realized with the example configuration:

- Output FDX4/5 at C2 (3. OSSD) switches off when the emergency stop at FDI0/1 (64. OSSD) and/or the light grid at FDI2/3 (63. OSSD) are activated.
- Output FDX6/7 at C5 (4. OSSD), if output FDX4/5 is switched. Signal forwarding to F-CPU.
- Non-safe channels at C4...C7 remain permanently on via the internal safe outputs (FSO0 and FSO1).
- The complete safety function is released via a release bit in the F-CPU (3. (OSSD).
- The state of output FDX4/5 is monitored via a CIP Safety bit in the F-CPU.

### Safely switch off FDX4/5 (3. OSSD)

Output FDX4/5 at C4 (3. OSSD) has to be switched off as soon as the emergency shutdown at FDI0/1 (64. OSSD) or the light grid at FDI2/3 (63. are activated. This means, the state of the OSSDs 63 and 64 controls the state of output FDX4/5.

- ▶ Delete **CIP Safety input** in 3. OSSD.
- ▶ Select the device **State of output switching element** from the device library and place it at the function input. In the dialog box **State of output switching element x** select OSSD 63 under **Assignment**.




Fig. 51: TSC – 3. OSSD, state of output switching element OSSD 63



- ▶ Select the device **State of output switching element** from the device library and place it at the function input. In the dialog box **State of output switching element x** select **OSSD 64** under **Assignment**.




Fig. 52: TSC – 3. OSSD, state of output switching element OSSD 63 and OSSD 64

- ⇒ The activation of the emergency shutdown at FDI0/1 or the light grid at FDI2/3 switches off output FDX4/5.

### Safely switch off FDX6/7 (4. OSSD)

Output FDX6/7 at C5 (4. OSSD) has to be switched off as soon as the emergency shutdown at FDX4/5 (3. OSSD) switches. This means, the state of the OSSD 3 controls the state of output FDX6/7.

- ▶ Delete **CIP Safety input** in 4. OSSD.
- ▶ Select the device **State of output switching element** from the device library and place it at the function input. In the dialog box **State of output switching element x** select OSSD 3 under **Assignment**.




Fig. 53: TSC – 4. OSSD, state of output switching element OSSD 3

⇒ The state of OSSD 3 controls the output FDX6/7 in OSSD 4.

### Release of the safety function via a release bit in the F-CPU

The release of the safety function is done using a release bit in the F-CPU. Therefore, an output bit of the F-CPU is assigned to the output function in the 3. OSSD.

- ▶ Select the element "CIP Safety input" in the Device library and place it at the third input of the function.




Fig. 54: TSC – release of the safety function via a release bit from the F-CPU

- ⇒ After an error, the safety function will only restart if the emergency shutdown as well as the light grid are error free and the release bit in the F-CPU is set.

### Monitoring an output in the F-CPU

The state of the output is monitored via a CIP Safety bit in the F-CPU.

- ▶ Open the **Output assignment** and assign a CIP Safety bit to output FDX4/5.



#### NOTE

Only the bits of the first two bytes (byte 0 and byte 1) are available for output assignment. Byte 2...7 are unused.




Fig. 55: TSC – output assignment CIP Safety bit

### 8.5.1 Checking and loading the configuration

The Turck Safety Configurator checks the created configuration for logical errors, which means, the logical wiring of the single components in the release circuits is checked. The configuration check does not consider double allocation etc.

- ▶ Start the check using the "Check configuration"-button.
- ▶ Load the configuration into the device via the Commissioning wizard ([▶ 51]) or by using the PC → **Monitor** function.

### 8.6 Configuring single channel safety sensors

If a slot is configured as **Single channel safety** in Turck Safety Configurator, then the double channel function for the slot is disabled.




Fig. 56: TSC – single channel inputs

No release circuits are generated for the single channel inputs. The OSSDs have to be created manually.

- ▶ Create an OSSD by using the **New window** function.




Fig. 57: TSC – creating a new window

- ▶ Add a **Single channel safety** input from the device catalog to the new window. Unused channels are displayed in **bold**.




Fig. 58: TSC – configuring an OSSD for a single channel safety input

- ▶ Link the single channel safe input with an CIP Safety Output.




Fig. 59: TSC – linking a single channel safe input with the PLC

- ▶ Add an automatic start and assign a CIP Safety bit in order to be able to monitor the single channel sensor from the PLC.




Fig. 60: TSC – single channel safe input with automatic start and CIP Safety assignment

## 8.7 Configuring the device at EtherNet/IP in Rockwell Studio 5000



### NOTE

Before starting the configuration in Rockwell Studio 5000:

- ▶ Close the Turck Safety Configurator.
- ▶ Restart the device.

### 8.7.1 Used Hardware

- TBIP-L...-FDIO1-2IOL  
Main IP-Address: 192.168.1.105
- Allen-Bradley Controller: Compact Logix 1769-L30ERMS/A LOGIX5370

### 8.7.2 Used Software

- RSLinx (Rockwell Automation)
- Studio 5000 (Rockwell Automation)
- Catalog file for Safety module

### Catalog files

Turck offers the catalog file „TURCK\_SAFETY\_BLOCK\_STATIONS\_V...L5K“ for the configuration of the devices in RSLogix/Studio5000 from Rockwell Automation.

The module entry TBIP-L...-FDIO1-2IOL creates a generic dual EtherNet/IP and CIP Safety connection, with module definitions pre-configured for both connections. Additionally, the CIP Safety I/O tags of the standard configuration from Turck Safety Configurator as well as configuration tags and I/O tags for the GPIO module are predefined.

The unique device name, the IP address, the SNN (Safety Network Number) and the Safety Configuration Signature must be assigned by the user depending on the application. If available, the user must also make additional module parameterizations for the GPIO behavior in the configuration tags.

The version of the catalog file used must match the revision of the RSLogix software used.



8.7.3 Creating a new project in Studio 5000

- ▶ Start Studio 5000.
- ▶ Click **New Project** select the used Safety controller and enter a project name.
- ▶ Confirm with **Next**.




Fig. 61: Studio 5000 – new project

- ▶ If necessary, adjust the settings in the **New Project** window and complete the project creation using the **Finish** button.




Fig. 62: Studio 5000 – finish the project creation

⇒ The new project is created and opened in the RSLogix Designer.




Fig. 63: Logix Designer – new project

8.7.4 Opening the catalog file

- ✓ The catalog file was downloaded from [www.turck.com](http://www.turck.com).
- ✓ The ZIP archive has been unpacked.
- ✓ The configuration of the with the Turck Safety Configurator is completed.
- ✓ A Studio 5000 project with the used CIP Safety PLC was created. [▶ 65]
- ▶ Open the catalog file in Studio 5000 by using the import function and save it as project.




Fig. 64: Studio 5000 – import of the catalog file

⇒ The project with the catalog file is created.




Fig. 65: Logix Designer – project with catalog file

### 8.7.5 Configuring the device in Logix Designer

Adding TBIP-L...-FDIO1-2IOL from catalog file to the project

Add the TBIP-L...-FDIO1-2IOL from the project with the catalog file under Ethernet to the new project.




Fig. 66: Logix Designer – adding TBIP-L5-FDIO1-2IOL to the project

### Assigning module properties

- ▶ In the **Module Properties** dialog, double-click the module entry and define a device name and the IP address (in the example 192.168.1.105).




Fig. 67: Logix Designer – setting name and IP address

### Set the the Configuration Signature

The Configuration Signature is used by the controller to clearly identify the safety device and assures that the configured device matches the connected device concerning the configured safety function. The Configuration Signature consists of an ID and a time stamp and is generated by the Turck Safety Configurator. The Configuration Signature is part of the configuration log.




Fig. 68: TSC – configuration log from the example project with Configuration Signature



**NOTE**

The time stamp in the configuration protocol of the Turck Safety Configurator is calculated depending on the system time (local time) of the computer on which the software is installed. The time in RSLogix Designer is though based on the UTC. Therefore, a conversion of the system-time based entry in the protocol to the UTC is necessary. In the example the CET (Central European Time) + 1 hour has to be entered in Logix Designer.

- ▶ Set the Configuration Signature under **Safety** → **Configuration Signature**.




Fig. 69: Logix Designer – entering the Configuration Signature from the configuration protocol

### Examples for calculating

CET (winter time)	UTC CET + 1 h	CEST (summer time)	UTC CEST + 2 h
1:34:00 000 PM	2:34:00 000 PM	2:34:00 000 PM	4:34:00 000 PM

- ▶ Save the **Module Properties** with **OK** and close the configuration.



### Defining the Project Path

- ▶ Scan the network via Communications → **Who Active**.
- ▶ Select the used controller.
- ▶ Define the project path via the **Set Project Path** button.




Fig. 70: Logix Designer – Who Active – setting the project path

- ▶ Close the **Who Active** window.

### Going Online with the Controller

- ▶ Click **Offline** → **Go Online**.
- ▶ Load the configuration into the controller by pressing the **Download** button in the **Connected To Go Online** window.
- ▶ Execute the download in the **Download** window by pressing the **Download** button.




Fig. 71: Logix Designer – downloading the configuration into the controller

- ⇒ The download is executed.

⇒ The TBIP-L...-FDIO1-2IOL (ETHERNET-SAFETY-STANDARD-MDOULE TBIP\_L5\_4FDI\_4FDX) in the project tree shows an error.




Fig. 72: Logix Designer – error at the device

- ▶ Open the module properties by double-clicking the device entry in the project tree.

- ⇒ The fault is specified under **Module Fault** in the **Connection** tab: "Safety network number mismatch".




Fig. 73: Logix Designer – copying the Safety Network Number

Before a connection to the device can be established, the CIP Safety Ownership must be configured. In this process the TBIP-L...-FDIO1-2IOL is assigned to the CIP Safety Controller via the Safety Network Number (SNN).

### Assigning the Safety Network Number

The Safety Network Number clearly assigns the safety I/O module to one CIP Safety Controller. In case of several controllers in one network, this inhibits an unintentional access of another controller to the safety device.

Copying the Safety Network Number from the controller

- ▶ Go offline.
- ▶ Open the **Controller Properties**.
- ▶ Click to ... (right to the Safety Network Number) in the **General** tab and open the the **Safety Network Number** window.
- ▶ Use the **Copy** button to copy the Safety Network Number and close the window with **OK**.




Fig. 74: Logix Designer – copying the Safety Network Number

Assigning the Safety Network Number to the device

- ▶ Open the **Module Properties** of the TBIP-L...-FDIO1-2IOL and open the **Safety Network Number** window by clicking the ... button.
- ▶ Use the **Paste** button to paste the controller's Safety Network Number into the module configuration and close the window with **OK**.




Fig. 75: Logix Designer – copying the Safety Network Number to the module properties

## Reset Ownership

If a device has already been used on a CIP Safety Controller, it must first be reset via a **Reset Ownership**.

- ▶ Go online.
- ▶ Click **Reset Ownership** in the **Safety** tab in the **Module Properties** and confirm all upcoming warnings.




Fig. 76: Logix Designer – Reset Ownership

- ▶ Open the **General** tab in the **Module Properties** and open the **Safety Network Number** window.

- ▶ In the **Safety Network Number** window, write the Safety Network Number to the device by clicking the **Set** button and confirm the setting.




Fig. 77: Logix Designer Writing the Safety Network Number to the device



## 9 Operating

### 9.1 LED displays

The device has the following LED indicators:

- Power supply
- Group and bus errors
- Status
- Diagnostics

LED PWR	Meaning
Off	No voltage connected or under voltage at V1
Green	Voltage V1 and V2 OK
Red	No valid state, device switches to the safe state
Red/green	No valid state, device switches to the safe state

LED 0...3 (C0...C1 or X0...X1)	Meaning
Off	Input active
Green	Input active
Green flashing	Self-test input
Red flashing	Cross Connection
Red	Discrepancy

LED 4...7 (C2...C3 or X2...X3)	Meaning	Channel is input	Channel is output
Off	Input active		Output inactive
Green	Input active		Output active
Green flashing	Self-test input		-
Red flashing	Cross Connection		-
red	Discrepancy		Overload

LED 0...7	Meaning
Red blinking, all alternating	Fatal Error



**NOTE**

The device executes a self-test after switching on the device. During the self test, MS and NS LED blink alternately red/green. Once the self test is completed, the MS LED continues blinking red/green, the NS LED extinguishes until the safety program in the device has been fully loaded. After the start-up, the LED states have the following meanings.

LED MS	Meaning
Off	Device not powered
Green	No diagnostics, device is operating in normal condition
Green flashing	<ul style="list-style-type: none"> <li>■ Use with safety controller, device is EtherNet/IP server: Device is in the Idle or Standby State.</li> <li>■ Use without safety controller: Device is protected mode, an EtherNet/IP client is currently connected to the standard I/Os.</li> </ul>
Red	Critical fault: device has an unrecoverable fault Device replacement may be necessary.
Red flashing	Recoverable fault
Green flashing/red	<ul style="list-style-type: none"> <li>■ During start-up: device in self test</li> <li>■ During operation: device needs commissioning due to configuration or Unique Node Identifier missing, incomplete or incorrect</li> </ul>

LED NS	Meaning
Off	<ul style="list-style-type: none"> <li>■ Device is not on-line.</li> <li>■ Device not powered</li> </ul>
Green	Active connection to a master
Green flashing	<ul style="list-style-type: none"> <li>■ Device on-line but no connection</li> <li>■ A connection may be established, but not completed.</li> </ul>
Red	Communication error
Red flashing	One or more I/O connections are in the timed-out state.
Green/red flashing	<ul style="list-style-type: none"> <li>■ During start-up: device is in self test</li> <li>■ During operation: network access error detected, communication failed (Communication Faulted State)</li> </ul>

LED WINK	Meaning
White flashing	Helps to localize the module if the Blink/Wink command is active

Note: The Ethernet ports P1 and P2 or XF1 and XF2 each have an LED ETH or L/A.

LEDs ETH... or L/A	Meaning
Off	No Ethernet connection
Green	Ethernet connection established, 100 Mbps
Green flashing	Ethernet traffic, 100 Mbps
Yellow	Ethernet connection established, 10 Mbps
Yellow blinking	Ethernet traffic, 10 Mbps

## 9.2 Status- and control word

### Status word

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	-	-	-	-	-	-	-	DIAG
Byte 0	-	FCE	-	-	-	COM	V1	-

Bit	Description
COM	Internal error The device-internal communication is disturbed.
DIAG	Diagnostic message at the device
FCE	The DTM Force Mode is activated. The actual output values may no match the ones defined and sent by the field bus.
V1	V1 too low (< 18 VDC)

### Control word

The control word is not in use.

## 9.3 Process input data

This chapter contains the description of the process input data of the safe I/O channels. The process input data of the IO-Link channels and the universal standard I/O channels are not safety-relevant and are only presented for the sake of completeness. The detailed description of the process data of the non-safety relevant channels can be found in the second and third parts of the operating manual.

### 9.3.1 Overview – complete module

The process input data of device are structured as follows:

	Word no.	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Status word	n	See [▶ 83]															
Basic	n + 1... n + 2	Status messages for standard I/O channels [▶ 103] and IO-Link master channels [▶ 122]															
Fieldbus bits	n + 3	Status of the safe unit [▶ 86]															
Safety status	n + 4... n + 10	Process input data safe I/O channels [▶ 85]															
IO-Link channels	n + 11... n + 42	IO-Link process input data [▶ 122]															
Diagnostics	n + 43	-	-	-	-	-	-	-	-	Overcurrent diagnostics [▶ 103]							
	n + 44	DXP-diagnostics [▶ 103]								-	-	-	-	-	-	-	-
	n + 45... n + 46	IO-Link port diagnostics [▶ 122]															
IO-Link Events	n + 46... n + 78	IO-Link Events [▶ 122]															
Module status	n + 79	Module status [▶ 83]															

9.3.2 Process input data – safe I/O channels

The safe inputs and outputs occupy 16 bytes of the process input image.

Word no.	Bit no.															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Status of the safe unit (fieldbus bits)</b>																
n + 3	FBI 1-7	FBI 1-6	FBI 1-5	FBI 1-4	FBI 1-3	FBI 1-2	FBI 1-1	FBI 1-0	FBI 0-7	FBI 0-6	FBI 0-5	FBI 0-4	FBI 0-3	FBI 0-2	FBI 0-1	FBI 0-0
<b>Safe Unit Status [▶ 86]</b>																
n + 4	-	-	-	-	-	-	-	-	-	-	-	-	-	SUM M	SUC M	SUPM
<b>Error Codes [▶ 87]</b>																
n + 5	-	-	-	-	-	-	-	-	-	-	-	68	67	66	65	64
<b>Memory and F-Config Status [▶ 87]</b>																
n + 6	-	-	-	-	-	-	-	-	FERR	--	-	COM LO	-	CN- FMM	NCNF	PMS
<b>Safe Status [▶ 87]</b>																
n + 7	Connector C1/X1								Connector C0/X0							
	OVL	-	TC CH1	TC CH0	ERR FIN	TEST	WAIT	RGG	OVL	-	TC CH1	TC CH0	ERR FIN	TEST	WAIT	RGG
n + 8	Connector C3/X3								Connector C2/X2							
	OVL	-	TC CH1	TC CH0	ERR FIN	TEST	WAIT	RGG	OVL	-	TC CH1	TC CH0	ERR FIN	TEST	WAIT	RGG
n + 9	Connector C5/X5								Connector C4/X4							
	OVL	-	TC CH1	TC CH0	ERR FIN	TEST	WAIT	RGG	OVL	-	TC CH1	TC CH0	ERR FIN	TEST	WAIT	RGG
n + 10	Connector C7/X7								Connector C6/X6							
	OVL	-	TC CH1	TC CH0	ERR FIN	TEST	WAIT	RGG	OVL	-	TC CH1	TC CH0	ERR FIN	TEST	WAIT	RGG

Field bus bits (status of the safe unit)

Word no.	Bit no.															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
n + 3	FBI 1-7	FBI 1-6	FBI 1-5	FBI 1-4	FBI 1-3	FBI 1-2	FBI 1-1	FBI 1-0	FBI 0-7	FBI 0-6	FBI 0-5	FBI 0-4	FBI 0-3	FBI 0-2	FBI 0-1	FBI 0-0

Bit	Description
FBI 0-4...FBI 1-7	Inputs in TBIP-L...-FDIO1-2IOL which can be addressed by the non-safe part of the safety controller. These bits have to be configured by the user in Turck Safety Configurator.



**NOTE**

The fieldbus bits FBI 1-0...FBI 1-7 are mapped to the inputs of the DXP channels of the non-safe side of the device (FBI 1-0 to DI8, FBI 1-1 to DI9, etc.).




Fig. 78: TSC – input assignment

Safe Unit Status

Name	Value	Meaning
SUPM	Safe Unit Protective Mode	
	0	Active
	1	Not active
SUCM	Safe Unit Configuration Mode	
	0	Active
	1	Not active
SUUM	Safe Unit Unknown Mode	
	0	Active
	1	Not active

## Error Codes

Code	Name	Meaning	Remedy
64 (0x40)	Destination Address Mismatch	The set IP address does not match the parameterized IP address.	<ul style="list-style-type: none"> <li>▶ Check parameterization</li> <li>▶ Restart the device.</li> </ul>
65 (0x41)	Invalid Destination Address	The set destination IP address is not valid. Addresses 0x00 and 0xFF are not allowed.	
66 (0x42)	Invalid Source Address	The set source IP address is not valid. Addresses 0x00 and 0xFF are not allowed.	
67 (0x43)	Invalid Watchdog-Time	Invalid value for watchdog time (F_WD_Time, F_WD_Time 2). A watchdog time of 0 ms is not allowed.	
68 (0x44)	SIL Value Exceeded	The required SIL level is not supported by the device.	

## Memory and F-Config Status

Name	Code	Meaning
PMS	512	No memory chip plugged
NCNF	513	No configuration available
CNFMM	514	Configuration mismatch
COMLO	516	Communication loss
FERR	519	Fatal Error

## Safe Status (connector C0...C7 or X0...X7)

Name	Code	Meaning
RGG	-	Normal State
WAIT	528	Wait for input signal
TEST	544	Test input
ERRFIN	560	Error at input
TCCH0	576	Cross-circuit channel 0
TCCH1	592	Cross-circuit channel 1

## 9.4 Process output data

This chapter contains the description of the process output data data of the safe I/O channels. The process output data of the IO-Link channels and the universal standard I/O channels are not safety-relevant and are only presented for the sake of completeness. The detailed description of the process data of the non-safety relevant channels can be found in the second and third parts of the operating manual.

### 9.4.1 Overview – complete module

The process output data of device are structured as follows:

	Word no.	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Basic	n + 1	Control: DXP channels															
Fieldbus bits	n + 2	Status of the safe unit [▶ 89]															
Safety status	n + 3	Unlock Safe Unit [▶ 88]															
IO-Link channels	n + 4 ... n + 5	IO-Link process output data [▶ 124]															

### 9.4.2 Process output data – safe I/O channels

Word no.	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
<b>Field bus bits</b> [▶ 89]																
n + 2	FBO15	FBO14	FBO13	FBO12	FBO11	FBO10	FBO9	FBO8	FBO7	FBO6	FBO5	FBO4	FBO3	FBO2	FBO1	FBO0
<b>Unlock Safe Unit</b> [▶ 88]																
n + 3	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	UNLK
n + 4	reserved															

#### Unlock Safe Unit

Name	Meaning
UNLK	This bit serves for unlocking the safe unit. It responds to a falling edge.

- ▶ Set bit UNLK to 1 and back to 0.
- ⇒ The safe unit is unlocked.



Fieldbus bits

Name	Meaning
FB0.0... FB1.7	In the Turck Safety Configurator, these output bits can be linked to states of the safe signals and used as inputs by the non-safe controller.

Output assignment

Device index	Symbol	Device name	CIP Safety	Fieldbus bit	Address	Name
0		CIP Safety input			[#0-3]	"0-3 CIP Safety Eingang"
1		CIP Safety input			[#0-2]	"0-2 CIP Safety Eingang"
2		CIP Safety input			[#0-1]	"0-1 CIP Safety Eingang"
3		CIP Safety input			[#0-0]	"0-0 CIP Safety Eingang"
4		TBIP-4.5-4FDI-4FDX (10000 1828)			[#FDI 6/7]	"FDI 6/7 Not-Halt"
5		TBIP-4.5-4FDI-4FDX (10000 1828)			[#FDI 4/5]	"FDI 4/5 Not-Halt"
6		TBIP-4.5-4FDI-4FDX (10000 1828)	0-0		[#FDI 2/3]	"FDI 2/3 Not-Halt"
7		Automatic start				"Automatischer Start#1"
8		Automatic start				"Automatischer Start#2"
9		Automatic start				"Automatischer Start#3"
10		Automatic start				"Automatischer Start#4"
11		Automatic start				"Automatischer Start#5"
12		Automatic start				"Automatischer Start#6"
13		Automatic start				"Automatischer Start#7"
14		TBIP-4.5-4FDI-4FDX (10000 1828)				"FDX 8/9 Sicherer Ausgang"
15		TBIP-4.5-4FDI-4FDX (10000 1828)				"FDX 10/11 Sicherer Ausgang"
16		TBIP-4.5-4FDI-4FDX (10000 1828)				"FDX 12/13 Sicherer Ausgang"
17		TBIP-4.5-4FDI-4FDX (10000 1828)				"FDX 14/15 Sicherer Ausgang"
18		CIP Safety output	1-4			"1-4 CIP Safety Ausgang"
19		CIP Safety output	1-5			"1-5 CIP Safety Ausgang"
20		CIP Safety output	1-6			"1-6 CIP Safety Ausgang"
S-1		TRUE				
S-16		Colors of all devices -				

Show all entries

Output type

Signal output     CIP Safety

PROFIsafe

Diagnostics output     Fieldbus bit

Data range:

Instance: 1

Local terminals...

Free outputs

--	1-0	2-0	3-0	4-0	5-0	6-0	7-0
0-1	1-1	2-1	3-1	4-1	5-1	6-1	7-1
0-2	1-2	2-2	3-2	4-2	5-2	6-2	7-2
0-3	1-3	2-3	3-3	4-3	5-3	6-3	7-3
0-4	--	2-4	3-4	4-4	5-4	6-4	7-4
0-5	--	2-5	3-5	4-5	5-5	6-5	7-5
0-6	--	2-6	3-6	4-6	5-6	6-6	7-6
0-7	1-7	2-7	3-7	4-7	5-7	6-7	7-7

Paste    Remove

Remove all assignments for CIP Safety

Remove current data range for CIP Safety

OK    Cancel    Help

Fig. 79: Output assignment in Turck Safety Configurator

## 9.5 Using the configuration memory

### 9.5.1 Storing a configuration

The safety function is automatically stored to the memory stick after a configuration has been downloaded to the device via Turck Safety Configurator.



#### NOTE

Non-safety-related configurations as the device's IP address will not be stored on the memory chip.

---

#### Storing the configuration during module start

- ✓ The device is not supplied.
- ✓ The memory chip is empty.
- ✓ The device has stored a valid configuration.
  - ▶ Plug the empty memory chip into the device.
  - ▶ Switch-on the power supply.
- ⇒ The configuration will be loaded from the device to the memory stick during device start.

#### Storing the configuration during operation

- ✓ The device is connected to the Turck Safety Configurator.
- ✓ The memory chip is plugged from the device start and contains the actual configuration (identical configuration as in the Turck Safety Configurator).
  - ▶ Load a new or changed configuration into the device via Turck Safety Configurator.

### 9.5.2 Loading a configuration from the memory chip

- ✓ Memory chip with valid configuration
  - ▶ Set the rotary coding switches to 900 (F\_Reset)
  - ▶ Execute a power cycle.
    - ⇒ The device is reset.
  - ▶ Set the rotary coding switch to an address unequal to "9xx".
  - ▶ Plug the memory chip containing a valid configuration onto the device.
  - ▶ Switch-on the power supply.
- ⇒ The configuration will be loaded from the memory chip to the device during device start.

### 9.5.3 Deleting the memory chip (Erase Memory)

The content of the memory chip can either be deleted by using the rotary coding switches or via the Turck Safety Configurator.

#### Deleting the configuration via rotary switch setting (901)

- ▶ Plug the memory chip into device.
- ▶ Set the rotary coding switches to 901 (Erase Memory).
- ▶ Execute a power cycle at the device.
- ⇒ The content of the memory chip is deleted. The procedure completed as soon as the ERR LED stops blinking.

### Deleting the configuration via Turck Safety Configurator

- ▶ Select the function **monitor settings** → **delete configuration** in the Turck Safety Configurator to delete the content of the memory stick.




Fig. 80: Deleting the configuration via Turck Safety Configurator

- ⇒ The configuration on the memory chip is deleted. The procedure completed as soon as the ERR LED stops blinking.

### 9.5.4 Configuration transfer and module behavior

Configuration		Device/ memory	Module behavior	Diagnostics
In device	External memory			
Invalid/ none	Invalid/ none	-	Device start → Device <b>not</b> running	No configuration available, see „Memory and F-Config Status“ [▶ 87]
Invalid/ none	Valid	-	Device start → Device running → Loading the configuration from the memory to the device	-
Valid	Invalid/ none	-	Device start → Device running → Loading the configuration from the device to the memory	-
Valid	Valid	equal	Device start → Device running	-

Configuration			Module behavior	Diagnostics
In device	External memory	Device/mem-ory		
Valid	Valid	unequal	Device start → Device running	Configuration miss-match, see „Memory and F-Config Status“ [▶ 87]
Valid	No memory chip plugged	-	Device start → Device <b>not</b> running	No memory chip plugged, see „Memory and F-Config Status“ [▶ 87]
Valid	Memory chip pulled	-	During operation	No memory chip plugged, see „Memory and F-Config Status“ [▶ 87]
changed during operation	Valid	unequal	During operation → The new configuration is checked. → Loading the configuration from the memory to the device	-

## 10 Restarting after Device Exchange or Modification

### 10.1 Changing a device



#### **DANGER**

Mounting or unmounting under voltage

**Personal damage due to unintentional machine start**

- ▶ Mount or unmount the device only in a de-energized condition.

#### 10.1.1 Prerequisites for device replacement

The replacement device has to be a device of the same type with the identical or a higher device version.

Observe for device replacement:

- ▶ The parameterization and the configuration of the exchange devices exactly matches the parameterization and the configuration of the device to be changed.
- ▶ Please follow the description under "Procedure for device replacement" to transfer an existing configuration from the configuration memory of the original device into the exchange device.

#### 10.1.2 Procedure for device replacement

- ✓ The device to be replaced must be in rotary mode [▶ 38].
- ▶ Disconnect the device to be replaced from the power supply and remove the memory chip with the valid configuration.
- ▶ **Important:** Do not mix up the memory chip.
- ▶ Take devices to be replaced out of operation according to chapter "Decommissioning" [▶ 94].
- ▶ Install the new device as described in the chapter "Installing" [▶ 21].
- ▶ Connect the device to the supply voltage with the power supply switched off [▶ 26].
- ▶ **Important:** Do not yet connect I/O level and Ethernet, do not plug memory chip.
- ▶ Optional: If the replacement device is not in the delivery state, reset the device to factory settings. To do this, proceed as follows:  
Set the rotary coding switch on the device to 900 (factory reset) [▶ 38], switch on the supply voltage, wait 1 min. and switch the device off again.
- ▶ A factory reset is not necessary for a device in the delivery state.
- ▶ Insert the memory chip with the valid configuration and set the IP address of the original device at the rotary coding switches [▶ 38].
- ▶ Close the service window.
- ▶ Switch on supply voltage and wait 1 min.
- ▶ Disconnect the device from the power supply again.
- ▶ Connect sensors and actuators as well as Ethernet cables [▶ 26].
- ▶ Switch on supply voltage.
- ▶ Check the safety configuration.
- ▶ Defective or faulty devices must not, in any event, be put back into circulation. Dispose of the devices as described in the chapter "Disposal" [▶ 94].

## 11 Maintenance

The TBIP-L...-FDIO1-2IOL is maintenance-free for the duration of use of 20 years.

Used cables as well as connected sensors and actuators have to be tested according to vendor specifications during the duration of use of TBIP-L...-FDIO1-2IOL.

## 12 Decommissioning

The machine manufacturer is responsible for decommissioning the TBIP-L...-FDIO1-2IOL. The operator must ensure that the device is used for its intended purpose.

Please observe the storage and transport requirements according to the general technical data.

## 13 Disposal



Defective or faulty devices must not, in any event, be put back into circulation. Send the devices back to Turck for testing and disposal.

## 14 Technical Data

### 14.1 General technical data

<b>Devices</b>	
TBIP-L5-FDIO1-2IOL	
■ ID	6814056
■ YoC	According to device labeling
TBIP-L4-FDIO1-2IOL	
■ ID	100000360
■ YoC	According to device labeling
TBIP-LL-FDIO1-2IOL	
■ ID	100027260
■ YoC	According to device labeling
<b>Supply</b>	
Connector	
■ TBIP-L5-FDIO1-2IOL	7/8", 5-pin
■ TBIP-L4-FDIO1-2IOL	7/8", 4-pin
■ TBIP-LL-FDIO1-2IOL	M12, L coded, 5-pin
V1 (incl. electronics supply)	24 VDC
V2	24 VDC, only through connected
Permissible range	20.4...28.8 VDC
Isolation voltages	≥ 500 VAC
<b>Interfaces</b>	
Ethernet	2 × M12, 4-pin, D coded
Service interface	Ethernet
<b>Times</b>	
Internal delay time (for calculating the Watch-dog time)	10 ms
Response times	See Safety Characteristic Data <a href="#">▶ 37</a>
<b>General technical data</b>	
Max. cable length	
■ Ethernet	100 m (per segment)
■ Sensor/actuator	30 m
Operating/storage temperature	-40 °C... +70 °C (-40 °F...+158 °F)
Protection class	IP67/IP69K The degree of protection is only guaranteed if unused connections are closed with suitable screw caps or blind caps.
Housing material	Fibre-glass reinforced Polyamide (PA6-GF30)
Window material	Lexan

<b>Tests</b>	
Vibration test	According to EN 60068-2-6, IEC 68-2-47, acceleration up to 20 g
Drop and topple	According to IEC 60068-2-31/IEC 60068-2-32
Shock test	According to EN 60068-2-27
Electro-magnetic compatibility	According to EN 61131-2/EN 61326-3-1

## 14.2 Technical data – safety inputs

<b>Safety inputs for OSSD</b>	
Signal voltage, low level	EN 61131-2 type 1 (< 5 V; < 0,5 mA)
Signal voltage, high level	EN 61131-2 type 1 (< 15 V; < 2 mA)
Max. OSSD supply per channel	2 A
Max. tolerated test pulse width	1 ms
Min. interval between two test pulses	12 ms at 1 ms test pulse width 8.5 ms at 0.5 ms test pulse width 7.5 ms at 0.2 ms test pulse width

<b>Safety inputs for potential free contacts</b>	
Loop resistance	< 150 Ω
Max. line capacity	Max. 1 μF at 150 Ω, limited by line capacity
Test pulse, typ.	0.6 ms
Test pulse max.	0.8 ms
Interval between two test pulses, min.	900 ms (for static inputs)




### 14.3 Technical data – safety outputs

**Safety outputs**

Suitable for inputs according to EN 61131-2, type 1

Output level in OFF-state	< 5 V
Output level in OFF-state	< 1 mA
Test pulse resistive load, max.	0.5 ms
Test pulse max.	1.25 ms
Interval between two test pulses, typical	500 ms
Interval between two test pulses, min.	250 ms
Max. output current	2 A (resistive)
Max. total current for device	9 A


Derating curve



Max. output current

2 A (DC load)

Derating curve



The user has to provide an additional overcurrent protection on site.

## TBIP-L...-FDIO1-2IOL – Standard DXP Channels

<b>15</b>	<b>Description of the Standard DXP Channels .....</b>	<b>99</b>
15.1	Functions and operating modes.....	100
15.1.1	DXP channel supply .....	100
<b>16</b>	<b>Connecting.....</b>	<b>101</b>
16.1	Connecting the device in Zone 2 and Zone 22 .....	101
16.2	Connecting digital sensors and actuators .....	101
<b>17</b>	<b>Configuring .....</b>	<b>102</b>
17.1	Parameters .....	102
<b>18</b>	<b>Operating .....</b>	<b>102</b>
18.1	LED displays – DXP channels .....	102
18.2	Process input data .....	103
18.2.1	Overview – complete module.....	103
18.2.2	Process input data – standard DXP channels .....	103
18.3	Process output data .....	104
18.3.1	Overview – complete module.....	104
18.3.2	Process_output_data – standard DXP channels .....	104
<b>19</b>	<b>Technical Data – DXP Channels.....</b>	<b>105</b>

## 15 Description of the Standard DXP Channels

The TBIP-L...-FDIO1-2IOL has two standard DXP channels.




Fig. 81: Device structure – DXP channels

TBEN-L4	TBEN-LL	Meaning
<b>TBEN-L5</b>		
X1	XD1	Power IN
X2	XD2	Power OUT
C0	X0	FDI0/1, safety-related input
C1	X1	FDI2/3, safety-related input
C2	X2	FDX4/5, safety-related input
C3	X3	FDX6/7, safety-related input
<b>C4</b>	<b>X4</b>	<b>DXP8/9, standard in-/outputs (safe shutdown via FSO0 possible)</b>
<b>C5</b>	<b>X5</b>	<b>DXP10/11, standard in-/outputs (safe shutdown via FSO0 possible)</b>
C6	X6	IOL, IO-Link port1
C7	X7	IOL, IO-Link port2 (safe shutdown via FSO 1 possible)
IP address	IP Address	Rotary coding switch for address setting (last byte of the IP address for the safe function unit)
P1	XF1	Ethernet 1
P2	XF2	Ethernet 2
FE	FE	Functional earth

## 15.1 Functions and operating modes

The universal digital DXP channels can be used as inputs or outputs depending on the application requirements. Up to four 3-wire PNP sensors or four PNP DC actuators with a maximum total output current of 2 A can be connected.

### 15.1.1 DXP channel supply

The two DXP channels are supplied via the internal safe output FSO0. The supply of the DXP channels via FSO0 enables the safety-related shutdown of the slots C4 and C5 Ethernet or respectively C4 and C5 or X4 and X5.



#### **NOTE**

The supply of the DXP channels via FSO0 is done by a pulsed voltage. The pulsed voltage can influence the function of connected sensors. To prevent this, the test pulse can be changed or switched off completely in the Turck Safety Configurator via the expert settings at the FSO0 output.

---

## 16 Connecting



### WARNING

Intrusion of liquids or foreign bodies through leaking connections

#### Danger to life due to failure of the safety function

- ▶ Tighten M12 connectors with a tightening torque of 0.6 Nm.
- ▶ Tighten 7/8" connectors with a tightening torque of 0.8 Nm.
- ▶ Only use accessories that guarantee the protection class.
- ▶ Close unused M12 connectors with the supplied screw caps. The tightening torque for the screw caps is 0.5 Nm.
- ▶ Use appropriate 7/8" sealing caps, e.g. type RKMV-CCC. The caps not part of the scope of delivery.

### 16.1 Connecting the device in Zone 2 and Zone 22



### DANGER

Potentially explosive atmosphere

#### Risk of explosion through spark ignition

#### When used in Zone 2 and Zone 22:

- ▶ Only disconnect and connect circuits when no voltage is applied.
- ▶ Only use connecting cables that are approved for use in potentially explosive atmospheres.
- ▶ Use all connectors or seal them with blind plugs.
- ▶ Observe requirements for Ex approval.

### 16.2 Connecting digital sensors and actuators

The device has two female M12 connectors for connecting standard digital sensors and actuators. The maximum tightening torque is 0.6 Nm.




Fig. 82: M12 connector, DXP channels C4...C5 or X4...X5

- ▶ Connect the digital sensors and actuators to the device according to the pin assignment.




Fig. 83: Pin assignment C4...C5 or X4...X5

## 17 Configuring

### 17.1 Parameters

The default values are written in **bold**.

Parameter name	Value	Meaning	Description
Manual output reset after overcurrent (SRO...)	<b>0</b>	<b>No</b>	The output switches on automatically after an overload.
	1	Yes	After an overcurrent, the output switches on again only after resetting and switching on again.
Activate output (EN DO...)	<b>0</b>	<b>No</b>	
	1	<b>Yes</b>	

## 18 Operating

### 18.1 LED displays – DXP channels

LED DXP 8...11 (C4...C5 or X4...X5)	Meaning (input)	Meaning (output)
Off	Input inactive	Output inactive
Green	Input active	Output active
Green/red flashing	Input active, overload at supply	-
Red blinking	Input inactive, overload at supply	Overload of the supply voltage
Red	-	Output active with overload or short circuit

## 18.2 Process input data

### 18.2.1 Overview – complete module

The process input data of device are structured as follows:

	Word no.	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Status word	n	See [▶ 83]															
Basic	n + 1... n + 2	Status messages for standard I/O channels [▶ 103] and IO-Link master channels [▶ 122]															
Fieldbus bits	n + 3	Status of the safe unit [▶ 86]															
Safety status	n + 4... n + 10	Process input data safe I/O channels [▶ 85]															
IO-Link channels	n + 11... n + 42	IO-Link process input data [▶ 122]															
Dia- gnostics	n + 43	-	-	-	-	-	-	-	-	Overcurrent diagnostics [▶ 103]							
	n + 44	DXP-diagnostics [▶ 103]								-	-	-	-	-	-	-	-
	n + 45... n + 46	IO-Link port diagnostics [▶ 122]															
IO-Link Events	n + 46... n + 78	IO-Link Events [▶ 122]															
Module status	n + 79	Module status [▶ 83]															

### 18.2.2 Process input data – standard DXP channels

	Word no.	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Basic	n + 1	-	-	-	-	DXP11 C5/X5 P2	DXP10 C5/X5 P4	DXP9 C4/X4 P2	DXP8 C4/X4 P4	-	-	-	-	-	-	-	-
...	...																
Dia- gnostics	n + 44	-	-	-	-	SCO11	SCO10	SCO9	SCO8	-	-	-	-	-	-	-	-

Meaning of the process data bits

Bit	Value	Meaning
DXP...	0	Input active
C.../X...P...	1	Input active
		C.../X... = connector C0...C7 (TBEN-L4 or TBEN-L5) X0...X7 (TBEN-LL) P ...= pin
SCO...	0	-
	1	Overcurrent at output

## 18.3 Process output data

### 18.3.1 Overview – complete module

The process output data of device are structured as follows:

	Word no.	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Basic	n + 1	Control: DXP channels															
Fieldbus bits	n + 2	Status of the safe unit [▶ 89]															
Safety status	n + 3	Unlock Safe Unit [▶ 88]															
IO-Link channels	n + 4 ... n + 5	IO-Link process output data [▶ 124]															

### 18.3.2 Process\_output\_data – standard DXP channels

	Word no.	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Basic	n + 1	-	-	-	-	DXP11 C5/X5 P2	DXP10 C5/X5 P4	DXP9 C4/X4 P2	DXP8 C4/X4 P4	-	-	-	-	-	-	-	-

Meaning of the process data bits

Bit	Value	Meaning
DXP...	0	Output inactive
C.../X...P...	1	Output active

C.../X... = connector  
C0...C7 (TBEN-L4 or TBEN-L5)  
X0...X7 (TBEN-LL)  
P ...= pin



## 19 Technical Data – DXP Channels

The first section of the operating instructions contains the general technical data of the device [► 95].

<b>Technical data</b>	
<b>Digital inputs</b>	
Number of channels	4
Input type	PNP
Switching threshold	EN 61131-2 type 3, PNP
Operating current	< 100 mA
Signal voltage low level	< 5 V
Signal voltage high level	> 11 V
Signal current low level	< 1.5 mA
Signal current high level	> 2 mA
Input delay	0.2 ms
Input frequency	400 Hz
Sensor supply	<ul style="list-style-type: none"> <li>■ C4/X4, C5/X5: FSO 0 max. 2 A; 500 mA per input</li> <li>■ C6/X6: VAUX1 max. 2 A</li> <li>■ C7/X7: FSO1 max. 2 A</li> </ul>
	Derating [► 97]
Potential isolation	Galvanic isolation to P1/P2, voltage proof up to 500 VAC
<b>Digital outputs</b>	
Number of channels	4, DC actuators
Output type	PNP
Output voltage	24 VDC
Load type	Ohmic
Output current per channel	0.5 A, short-circuit proof, max. 2 A (ohmic) 1 A (inductive) over all standard outputs
Simultaneity factor	1 for the complete module Total current max. 2 A at FSO0
Actuator supply	<ul style="list-style-type: none"> <li>■ C4/X4, C5/X5: FSO 0 max. 2 A; 500 mA per output</li> <li>■ C6/X6: VAUX1 max. 2 A</li> <li>■ C7/X7: FSO1 max. 2 A</li> </ul>
	Derating [► 97]
Potential isolation	Galvanic isolation to P1/P2, voltage proof up to 500 VAC

## TBIP-L...-FDIO1-2IOL – Standard IO-Link Channels

<b>20</b>	<b>Description of the IO-Link Channels .....</b>	<b>107</b>
<b>20.1</b>	<b>Functions and operating modes.....</b>	<b>108</b>
20.1.1	Power supply of the IO-Link ports .....	108
20.1.2	Supply of connected IO-Link devices (Class A and Class B).....	108
<b>21</b>	<b>Connecting.....</b>	<b>109</b>
<b>21.1</b>	<b>Connecting the device in Zone 2 and Zone 22 .....</b>	<b>109</b>
<b>21.2</b>	<b>Connecting IO-Link Devices.....</b>	<b>110</b>
<b>22</b>	<b>Commissioning.....</b>	<b>112</b>
<b>22.1</b>	<b>Commissioning an IO-Link device with IO-Link V1.0.....</b>	<b>112</b>
<b>22.2</b>	<b>Commissioning an IO-Link device with IO-Link V1.1 .....</b>	<b>113</b>
<b>23</b>	<b>Configuring .....</b>	<b>115</b>
<b>23.1</b>	<b>Parameters .....</b>	<b>115</b>
23.1.1	Adapting process data mapping .....	119
<b>24</b>	<b>Operating .....</b>	<b>120</b>
<b>24.1</b>	<b>LED displays – IO-Link channels.....</b>	<b>120</b>
<b>24.2</b>	<b>Process input data .....</b>	<b>121</b>
24.2.1	Overview – complete module.....	121
24.2.2	Process input data – IO Link channels.....	122
<b>24.3</b>	<b>Process output data .....</b>	<b>124</b>
24.3.1	Overview – complete module.....	124
24.3.2	Process output data – IO Link channels .....	124
<b>24.4</b>	<b>Software diagnostic messages.....</b>	<b>125</b>
<b>24.5</b>	<b>IO-Link functions for acyclic communication.....</b>	<b>128</b>
24.5.1	Port functions for Port 0 (IO-Link Master) .....	128
<b>24.6</b>	<b>Using the data storage mode .....</b>	<b>134</b>
24.6.1	Parameter "Data storage mode" = activated.....	134
24.6.2	Parameter "Data storage mode" = read in.....	135
24.6.3	Parameter "Data storage mode" = overwrite .....	136
24.6.4	Parameter "Data storage mode" = deactivated, clear .....	136
<b>25</b>	<b>Troubleshooting .....</b>	<b>137</b>
<b>25.1</b>	<b>Eliminating parameterization errors.....</b>	<b>137</b>
<b>26</b>	<b>Technical Data – IO-Link Channels .....</b>	<b>138</b>

## 20 Description of the IO-Link Channels

The TBIP-L...-FDIO1-2IOL provides two IO-Link ports at the connectors C6 and C7 or X6 and X7.

- 2-channel IO-Link master according to specification V1.1
- two universal digital channels, PNP, channel diagnostics, 0.5 A




Fig. 84: Device structure – IO-Link channels

TBEN-L4	TBEN-LL	Meaning
<b>TBEN-L5</b>		
X1	XD1	Power IN
X2	XD2	Power OUT
C0	X0	FDI0/1, safety-related input
C1	X1	FDI2/3, safety-related input
C2	X2	FDX4/5, safety-related in-/output
C3	X3	FDX6/7, safety-related in-/output
C4	X4	DXP8/9, standard in-/outputs (safe shutdown via FSO0 possible)
C5	X5	DXP10/11, standard in-/outputs (safe shutdown via FSO0 possible)
<b>C6</b>	<b>X6</b>	<b>IOL, IO-Link port 1</b>
<b>C7</b>	<b>X7</b>	<b>IOL, IO-Link port 2 (safe shutdown via FSO 1 possible)</b>
IP Address	IP Address	Rotary coding switch for address setting (last byte of the IP address for the safe function unit)
P1	XF1	Ethernet 1
P2	XF2	Ethernet 2
FE	FE	Functional earth

## 20.1 Functions and operating modes

The TBIP-L...-FDIO1-2IOL has two Class A IO-Link ports at slots C6 and C7 or X6 and X7.

The IO-Link channels at pin 4 can be parameterized independently of each other and operated either in IO-Link mode or in SIO mode (DI in standard I/O mode).

The universal digital channels at pin 2 of the slots C6 and C7 or X6 and X7 are designed as DXP channels and can be freely used as input or output.

### 20.1.1 Power supply of the IO-Link ports

The IO-Link port IOL1 at C6 or X6 is supplied via V1. The IO-Link port IOL2 at C7 or X7 is supplied via the internal safe output FSO1.

IO-Link port	Connector	Power supply
IOL1	C6/X6	VAUX1
IOL2	C7/X7	FSO1 (clocked by test pulses)



#### NOTE

The supply of the IO channels IOL2 via FSO1 is done by a pulsed voltage. The pulsed voltage can influence the function of connected IO-Link devices to the device. To prevent this, the test pulse can be changed or switched off completely in the Turck Safety Configurator via the expert settings at the FSO1 output.

### 20.1.2 Supply of connected IO-Link devices (Class A and Class B)

The IO-Link ports provide Class A power on pins 1 and 3 and Class B power on pins 2 and 5 for the connected IO-Link devices. The two supply voltages are not galvanically isolated.

Set the respective output (DXP13 or DXP15) in the process output data in order to activate the Class B supply, [▶ 124].

## 21 Connecting



### **WARNING**

Intrusion of liquids or foreign bodies through leaking connections

#### **Danger to life due to failure of the safety function**

- ▶ Tighten M12 connectors with a tightening torque of 0.6 Nm.
  - ▶ Tighten 7/8" connectors with a tightening torque of 0.8 Nm.
  - ▶ Only use accessories that guarantee the protection class.
  - ▶ Close unused M12 connectors with the supplied screw caps. The tightening torque for the screw caps is 0.5 Nm.
  - ▶ Use appropriate 7/8" sealing caps, e.g. type RKMV-CCC. The caps not part of the scope of delivery.
- 

### 21.1 Connecting the device in Zone 2 and Zone 22



### **DANGER**

Potentially explosive atmosphere

#### **Risk of explosion through spark ignition**

##### **When used in Zone 2 and Zone 22:**

- ▶ Only disconnect and connect circuits when no voltage is applied.
  - ▶ Only use connecting cables that are approved for use in potentially explosive atmospheres.
  - ▶ Use all connectors or seal them with blind plugs.
  - ▶ Observe requirements for Ex approval.
-

## 21.2 Connecting IO-Link Devices

The device has two M12 connectors for connecting IO-Link devices. The maximum tightening torque is 0.6 Nm.




Fig. 85: M12 connector, IO channel IOL1, C6 or X6

- ▶ Connect the IO-Link devices to the device according to the pin assignment.




Fig. 86: Pin assignment IO-Link port IOL1 (C6 or X6)

Pin	Signal	Meaning
1	V <sub>AUX1</sub>	Class A supply
2	DI/DO	Digital input or digital output/Class B supply
3	GND (V1)	Ground V1
4	C/Q	IO-Link
5	GND (V1)	Functional earth




Fig. 87: M12 connector, IO channels IOL2, C7 or X7

- ▶ Connect the IO-Link devices to the device according to the pin assignment.




Fig. 88: Pin assignment IO-Link port IOL2 (C7 or X7)

Pin	Signal	Meaning
1	FSO1	Class A supply (can be switched off safely)
2	DI/DO	Digital input or digital output/Class B supply
3	GND (V1)	Ground V1
4	C/Q	IO-Link
5	GND (V1)	Functional earth



**NOTICE**

Wrong supply of IO-Link devices (Class A)

**Damage to the electronics**

- ▶ Only supply IO-Link devices (Class A) with the voltage VAUX1 provided at the supply terminals.

Connecting Inductive Coupler (Class A)

The IO-Link port IOL2 at C7 or X7 is supplied via the internal safe output FSO1. Inductive couplers (Class A) cannot be connected to port C7 or X7 due to the test pulses of the safe output.

- ▶ Only connect inductive couplers to port C6 or X6.
- ▶ Set the parameter "Cycle time" to a minimum value of 10.4 ms.

## 22 Commissioning

### 22.1 Commissioning an IO-Link device with IO-Link V1.0

IO-Link devices in accordance with IO-Link specification V1.0 do not support data storage. If an IO-Link V1.0 device is used, data storage on the IO-Link port must be deactivated.

- ▶ Set **Data storage mode** at the port to **deactivated, clear**.
- ▶ Load the parameter changes into the device.
- ▶ Connect the IO-Link V1.0 device.
- ⇒ The LED IOL at the IO-Link port is green, IO-Link communication active.




Fig. 89: Deactivate or respectively delete the data storage mode with the DTM (example).



## 22.2 Commissioning an IO-Link device with IO-Link V1.1

The data storage of the master should be cleared before a device with a different device type is connected to an IO-Link port which has already been used before.

The data storage memory of the master can be deleted in two ways:

- Set back the master to factory settings.
- Delete the data storage memory via the parameter **Data storage mode**.

Resetting the master to factory settings with the DTM

- ▶ From the **Factory settings** drop-down menu, select **Set to factory settings**.
- ▶ Load the parameter changes into the device.
- ⇒ The DTM resets the device automatically.




Fig. 90: Reset device to factory settings via DTM (example)

- ▶ Connect the IO-Link V1.1 device.
- ⇒ The LED IOL at the IO-Link port is green, IO-Link communication active.

Delete the data storage memory via parameters

- ▶ Set Data storage mode to **deactivated, clear**.
- ▶ Load the parameter changes into the device.
- ▶ Re-activate the data storage, if necessary.
- ▶ Load the parameter changes into the device.
- ▶ Connect the IO-Link V1.1 device.
- ⇒ The LED IOL at the IO-Link port is green, IO-Link communication active.




Fig. 91: Deactivate or respectively delete the data storage mode with the DTM (example).

## 23 Configuring

### 23.1 Parameters

	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
		<b>Basic</b>							
	0	-	-	-	-	-	-	-	-
	1	DXP15_ SRO	-	DXP13_ SRO	-	-	-	-	-
	2	-	-	-	-	-	-	-	-
	3	DXP15_ ENDO	-	DXP14_ ENDO	-	-	-	-	-
		<b>IO-Link</b>							
<b>IOL1</b>	4	GSD	Quick Start-Up	data storage mode		Operation mode			
	5	Cycle time							
	6	Process output data mapping		Process input data mapping		Deactivate diagnostics		PDIN invalid	Revision
	7...11	-	-	-	-	-	-	-	-
	12	Vendor ID (LSB)							
	13	Vendor ID (MSB)							
	14	Device ID (LSB)							
	15	Device ID							
	16	Device ID							
	17	Device ID (MSB)							
	18	-	-	-	-	-	-	-	-
	19	-	-	-	-	-	-	-	-
<b>IOL2</b>	20...35	Assignment similar to IOL1 (byte 4 to 19)							

## Meaning of parameter bits

The default values are written in **bold**.

Parameter name	Value		Meaning	Description
	dec.	Hex.		
Operation mode	<b>0</b>	<b>0x00</b>	<b>IO-Link without validation</b>	Pin 4 is operated in IO-Link mode. The master does not check if the connected device matches the configured one.
	1	0x01	IO-Link with family compatible device	Pin 4 is operated in IO-Link mode. The master checks if the vendor ID and the MSB of the device ID (this byte defines the product family) of the connected device match those of the configured one. If the master detects a mismatch, the IO-Link communication is established, but there is no process data exchange. The device remains in the safe state (Pre-Operate). Parameters and diagnostic information can be read and respectively written.
	2	0x02	IO-Link with compatible device	Pin 4 is operated in IO-Link mode. The master checks if the vendor ID and the device ID of the connected device match those of the configured one. If the vendor ID matches, but the device ID not, then the master tries to write the device ID to the device. If the writing is successful, then the device is a compatible one, process data exchange is possible. If writing the device ID is not successful, then process data exchange is not possible. The device remains in the safe state (Pre-Operate). Parameters and diagnostic information can be read and respectively written.
	3	0x03	IO-Link with identical device	Pin 4 is operated in IO-Link mode. The master checks if the device type (vendor ID and device ID) and the serial number of the connected device match the data of the configured one. If the master detects a mismatch, the IO-Link communication is established, but there is no process data exchange. The device remains in the safe state (Pre-Operate). Parameters and diagnostic information can be read and respectively written.
	4	0x04	DI (with parameter access)	Pin 4 is generally operated as simple digital input. However, an acyclic parameter access from the PLC or the DTM is possible. The IO-Link master starts the port in IO-link mode, parameterizes the device and sets the port back into SIO mode (SI). The port remains in SIO mode (DI) until a new IO-Link request is sent from the higher-level control. Data storage is not supported. Connected devices have to support the SIO mode (DI). In case of a parameter access, the IO-Link communication at the port is started. Switching signals are interrupted.
	8	0x08	DI	Pin 4 is operated as simple digital input. Data storage is not supported.

Parameter name	Value dec.	Value Hex.	Meaning	Description
Data storage mode	Synchronization of parameter data of IO-Link devices (storing the parameter of the connected device in the master). If the synchronization is not possible, a diagnostic message is displayed (DS_ERR). In this case the data memory of the master must be deleted: ▶ Select option "11 = deactivated, delete" to delete the data memory of the master  IO-Link devices in accordance with IO-Link specification V1.0 do not support data storage. When using IO-Link devices with IO-Link V1.0: ▶ Select option "11 = deactivated, delete" to deactivate data storage.			
	0	0x00	Activated	Synchronization of parameter data activated. The actual data (master or device) serve as the reference data.
	1	0x01	overwrite	Synchronization of parameter data activated, the data in the master serve as reference data.
	2	0x02	read in	Synchronization of parameter data activated. The data in the connected IO-Link device serve as reference data.
	3	0x03	Deactivated, clear	Synchronization of parameter data deactivated. The data set in the master is deleted.
Activate Quick Start-Up	For fast applications (e.g. tool changing applications) the start-up time of IO-Link devices can be shortened. The start-up time defined in the IO-Link specification (TSD = Device Detection Time) is reduced.			
	0	0x00	No	The start-up time is within the specified range (0.5 s). All IO-Link devices in accordance with the specification can be operated.
	1	0x01	Yes	The start-up time is reduced to approx. 100 ms. It is not supported by every IO-Link device. It can thus be necessary to check if the used IO-Link device starts in this mode.
Device parameterization via GSD (GSD)	0	0x00	inactive	The port is generic or is not parameterized.
	1	0x01	Active	In PROFINET the port is parameterized with a specific device type from the GSDML-file.
Cycle time	0	0x00	Automatic	The lowest cycle time supported by the device is taken from the table.
	16... 191	0x10 ...	1.6 = 132,8 ms	Settable in steps of 0.8 or 1.6 ms.
	255	0xFF	Automatic, compatible	Compatibility mode The mode solves possible communication problems with sensors of the SGB family from IFM.
Revision	0	0x00	Automatic	The Master defines the IO-Link revision automatically.
	1	0x01	V1.0	IO-Link Revision V 1.0 is used.
Process input data invalid (PDIN invalid)	0	0x00	Diagnostic generated	If the process data are invalid, a respective diagnostic message is generated.
	1	0x01	No diagnostic generated	Invalid process data do not cause a diagnostic message.

Parameter name	Value		Meaning	Description
	dec.	Hex.		
Deactivate diagnostics	Influences the sending of IO-Link-Events from the master to the fieldbus. Depending on the parameterization, the master transmits Events based on their priority to the fieldbus or not.			
	0	0x00	No	The master transmits all IO-Link Events to the fieldbus.
	1	0x01	Notifications	The master transmits all IO-Link Events to the fieldbus except for IO-Link notifications.
	2	0x02	<b>Notifications and warnings</b>	The master transmits all IO-Link Events to the fieldbus except for IO-Link notifications and warnings.
	3	0x03	Yes	The master doesn't transmit any IO-Link Event to the fieldbus.
Process input data mapping	Optimization of the process data mapping for the used fieldbus: The IO-Link-data can be swapped depending on the used fieldbus in order to achieve an optimized data mapping on the fieldbus side.			
	0	0x00	Direct	The process data are not swapped. i.e.: 0x0123 4567 89AB CDEF
	1	0x01	<b>Swap 16 bit</b>	The bytes are swapped per word. i.e.: 0x2301 6745 AB89 EFCD
	2	0x02	Swap 32 bit	The bytes are swapped per double word. i.e.: 0x6745 2301 EFCD AB89
	3	0x03	swap all	All bytes are swapped. i.e.: 0xEFCD AB89 6745 2301
<b>Process output data mapping</b>	see <b>Process input data mapping</b>			
Vendor ID	0...65535 0x0000...0xFFFF		Vendor ID for the port configuration check	
Device ID	0...16777215 0...0x0FFFFFFF		Device ID for the port configuration check 24 bit value	

Values for the parameter "cycle time" in ms:

Time	Value	Time	Value	Time	Value	Time	Value	Time	Value	Time	Value		
auto	0x00	16	0x58	31.2	0x7E	60.8	0x92	91.2	0xA5	121.6	0xB8		
1.6	0x10	16.8	0x5A	32	0x80	62.4	0x93	92.8	0xA6	123.2	0xB9		
2.4	0x18	17.6	0x5C	33.6	0x81	64	0x94	94.4	0xA7	124.8	0xBA		
3.2	0x20	18.4	0x5E	35.2	0x82	65.6	0x95	96	0xA8	126.4	0xBB		
4	0x28	19.2	0x60	36.8	0x83	67.1	0x96	97.6	0xA9	128	0xBC		
4.8	0x30	20	0x62	38.4	0x84	68.8	0x97	99.2	0xAA	129.6	0xBD		
5.6	0x38	20.8	0x67	40	0x85	70.4	0x98	100.8	0xAB	131.2	0xBE		
6.4	0x40	21.6	0x66	41.6	0x86	72	0x99	102.4	0xAC	132.8	0xBF		
7.2	0x42	22.4	0x68	43.2	0x87	73.6	0x9A	104	0xAD	reserved			
8	0x44	23.2	0x6A	44.8	0x88	75.2	0x9B	105.6	0xAE				
8.8	0x46	24.0	0x6C	46.4	0x89	76.8	0x9C	107.2	0xAF				
9.6	0x48	24.8	0x6E	48	0x8A	78.4	0x9D	108.8	0xB0				
10.4	0x4A	25.6	0x70	49.6	0x8B	80	0x9E	110.4	0xB1				
11.2	0x4C	26.4	0x72	51.2	0x8C	81.6	0x9F	112	0xB2				
12.0	0x4E	27.2	0x74	52.8	0x8D	83.2	0xA0	113.6	0xB3				
12.8	0x50	28	0x76	54.4	0x8E	84.8	0xA1	115.2	0xB4				
13.6	0x52	28.8	0x78	56	0x8F	86.4	0xA2	116.8	0xB5				
14.4	0x54	29.6	0x7A	57.6	0x90	88	0xA3	118.4	0xB6				
15.2	1x56	30.4	0x7C	59.2	0x91	89.6	0xA4	120	0xB7			auto., comp.	0xFF

### 23.1.1 Adapting process data mapping

The mapping of process data can be adapted application-specifically via the IO-Link master's parameterization.

Depending on the used fieldbus, it can be necessary to swap process data word-wise, double word-wise or completely in order to align them to the data structure in the PLC. The process data mapping is determined channel by channel through the parameters **process input data mapping** and **process output data mapping**.

## 24 Operating

### 24.1 LED displays – IO-Link channels

<b>LED IOL, LED 12 (C6/X6), LED14 (C7/X7)</b>	<b>Meaning (Channel in IO-Link-mode)</b>	
Off	Port inactive, no IO-Link communication, diagnostics deactivated	
Green flashing	IO-Link communication, process data valid	
Red flashing	IO-Link communication and module error, invalid process data	
Red	IO-Link supply error free, no IO-Link communication and/ or module error, process data invalid	

<b>LED IOL, LED 12 (C6/X6), LED14 (C7/X7)</b>	<b>Meaning (channel in SIO mode (DI))</b>	
Off	No input signal	
Green	Digital input signal active	

<b>LED DXP, LED 13 (C6/X6), LED15 (C7/X7)</b>	<b>Meaning (input)</b>	<b>Meaning (output)</b>
Off	Input active	Output inactive
Green	Input active	Output active
Red	–	Output active with overload or short-circuit



## 24.2 Process input data

### 24.2.1 Overview – complete module

The process input data of device are structured as follows:

	Word no.	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Status word	n	See [▶ 83]															
Basic	n + 1... n + 2	Status messages for standard I/O channels [▶ 103] and IO-Link master channels [▶ 122]															
Fieldbus bits	n + 3	Status of the safe unit [▶ 86]															
Safety status	n + 4... n + 10	Process input data safe I/O channels [▶ 85]															
IO-Link channels	n + 11... n + 42	IO-Link process input data [▶ 122]															
Diagnostics	n + 43	-	-	-	-	-	-	-	-	Overcurrent diagnostics [▶ 103]							
	n + 44	DXP-diagnostics [▶ 103]								-	-	-	-	-	-	-	-
	n + 45... n + 46	IO-Link port diagnostics [▶ 122]															
IO-Link Events	n + 46... n + 78	IO-Link Events [▶ 122]															
Module status	n + 79	Module status [▶ 83]															

24.2.2 Process input data – IO Link channels

Word no.	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
<b>Basic</b>																
n + 1	DXP15 C7/X7 P2	DI14 C7/X7 P4	DXP13 C6/X6 P2	DI12 C6/X6 P4	-	-	-	-	-	-	-	-	-	-	-	-
n + 2	-	DVS14	-	DVS12	-	-	-	-	-	-	-	-	-	-	-	-
<b>IO-Link process input data</b>																
n + 11 ... n + 26	IOL1 process input data (connector C6/X6) structure depends on channel parameterization															
n + 27 ... n + 42	IOL2 process input data (connector C7X7) structure depends on channel parameterization															
<b>Overcurrent diagnostics sensor supply (IOL1)</b>																
n + 43	-	-	-	-	-	-	-	-	-	-	VERR V1 K1213	-	-	-	-	-
<b>Overcurrent output</b>																
n + 44	SCO15	-	SCO13	-	-	-	-	-	-	-	-	-	-	-	-	-
<b>IO-Link port diagnostics– IOL1 (connector C6/X6)</b>																
n + 45	GEN- ERR	OVL	VHIGH	VLOW	ULVE	LLVU	OTMP	PRM ERR	EVT1	EVT2	PD INV	HW ERR	DS ERR	CFG ERR	PPE	-
<b>IO-Link port diagnostics– IOL2 (connector C7/X7)</b>																
n + 46	GEN- ERR	OVL	VHIGH	VLOW	ULVE	LLVU	OTMP	PRM ERR	EVT1	EVT2	PD INV	HW ERR	DS ERR	CFG ERR	PPE	-
<b>IO-Link Events</b>																
n + 47	Port (1st Event)									Qualifier (1st Event)						
n + 48	Event code low byte (1st Event)									Event code high byte (1st Event)						
...																
n + 77	Port (16th Event)									Qualifier (16th Event)						
n + 78	Event code low byte (16th Event)									Event code high byte (16th Event)						

Meaning of the process data bits

Name	Value	Meaning
<b>I/O data</b>		
DXP... C.../X...P...	Configurable digital channel (DXP channel)	C.../X... = connector C0...C7 (TBEN-L4 or TBEN-L5) X0...X7 (TBEN-LL) P ...= pin
	0	No input signal at DXP channel (pin 2)
	1	Input signal at DXP channel (pin 2)
DVS...	Input value valid (Data Valid Signal)	
	0	The IO-Link data are invalid. Possible causes: <ul style="list-style-type: none"> <li>■ Sensor supply is pending below the admissible range.</li> <li>■ IO-Link port is parameterized as simple digital input.</li> <li>■ No device connected to the master.</li> <li>■ No input data received from the connected device (only valid for devices with an input data length &gt; 0).</li> <li>■ No reaction from the connected device to the sending of output data (only valid for devices with an output data length &gt; 0).</li> <li>■ The connected device sends an error <b>Process input data invalid</b>.</li> </ul>
	1	The IO-Link data are valid.
IO-Link process input data	Process input data of the connected device The order of the IO-Link process input data can be changed via the parameter <b>Process input data mapping</b> .	
<b>Diagnostics</b>		
SCO...	Overcurrent output	
	0	No overcurrent
	1	Overcurrent at output (DXP channel used as output)
<b>IO-Link port diagnostics</b>	s. "Software diagnostic messages", [▶ 125]	
<b>IO-Link Events</b>	s. "IO-Link Events", [▶ 128]	

## 24.3 Process output data

### 24.3.1 Overview – complete module

The process output data of device are structured as follows:

	Word no.	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Basic	n + 1	Control: DXP channels															
Fieldbus bits	n + 2	Status of the safe unit [► 89]															
Safety status	n + 3	Unlock Safe Unit [► 88]															
IO-Link channels	n + 4 ... n + 5	IO-Link process output data [► 124]															

### 24.3.2 Process output data – IO Link channels

Word no.	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
<b>Basic</b>																
n + 1	DXP15 C7/X7 P2	-	DXP13 C6/X6 P2	-	-	-	-	-	-	-	-	-	-	-	-	-
...	...															
<b>IO-Link process output data</b>																
n + 4 ... n + 19	IOL1 (connector C6/X6) structure depends on the channel parameterization (0...32 byte per channel)															
n + 20 ... n + 35	IOL2 (connector C7/X7) structure depends on the channel parameterization (0...32 byte per channel)															

Meaning of the process data bits

Name	Value	Meaning
<b>I/O data</b>		
DXP...	0	Output inactive
C.../X...P...	1	Output active, max. output current 0.6 A
		C.../X... = connector C0...C7 (TBEN-L4 or TBEN-L5) X0...X7 (TBEN-LL) P ...= pin
IO-Link process output data		Process output data of the connected device The order of the IO-Link process output data can be changed via the parameter <b>Process output data mapping</b> .

## 24.4 Software diagnostic messages

Diagnostic messages are divided into DXP, IO-Link master and IO-Link device diagnostics.

The "PDInvalid" diagnostic (process data invalid) can be sent from both devices, IO-Link master or IO-Link device.

- **DXP diagnostics:**

Diagnostic messages of the universal digital channels (DXP13 and DXP15)

- **IO-Link master diagnostics (M):**

The IO-Link-master reports problems within the IO-Link communication.

- **IO-Link device diagnostics (D):**

The device diagnostics map the IO-Link Event Codes (according to the IO-Link specification) sent from the IO-Link devices to the diagnostic telegram of the master.

Event codes can be read from the connected devices by using appropriate device tools (e.g. IODD Interpreter).

Further information concerning the IO-Link Event Codes and their meaning can be found in the IO-Link specification or in the documentation of the connected devices.

Byte no.	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
<b>DXP diagnostics – overcurrent sensor supply</b>								
0	-	VERR V1 K1213	-	-	-	-	-	-
1	-	-	-	-	-	-	-	-
2	-	-	-	-	-	-	-	-
3	SCO15	-	SCO13	-	-	-	-	-
<b>IO-Link port 1 (channel 12)</b>								
0	EVT1 (D)	EVT2 (D)	PDINV (D, M)	HWERR (D)	DSERR (M)	CFGERR (M)	PPE (M)	-
1	GENERR (D)	OLV (D)	VHIGH (D)	VLOW (D)	ULVE (D)	LLVU (D)	OTEMP (D)	PRMERR (D)
<b>IO-Link port 2 (channel 14)</b>								
2	EVT1 (D)	EVT2 (D)	PDINV (D, M)	HWERR (D)	DSERR (M)	CFGERR (M)	PPE (M)	-
3	GENERR (D)	OLV (D)	VHIGH (D)	VLOW (D)	ULVE (D)	LLVU (D)	OTEMP (D)	PRMERR (D)

Bit	Meaning
<b>DXP diagnostics</b>	
VERRV1 K1213	Overcurrent supply VAUX1 on channel 12/13
SCO...	Overcurrent at output (DXP channel used as output)
<b>IO-Link master diagnostics</b>	
CFGERR	Wrong or missing device The connected device does not match the channel configuration or there is no device connected to the channel. This diagnostic message depends on the parameterization of the channel.

Bit	Meaning
DSER	Data storage error Possible causes: <ul style="list-style-type: none"> <li>■ Data storage mismatch: IO-Link device in accordance with IO-Link V1.0 connected ☒ The data storage buffer contains data of another device.</li> <li>■ Overflow of the data storage buffer</li> <li>■ The connected device may be locked for parameter changes or for data storage.</li> </ul>
PPE	Port parameterization The port parameters are inconsistent. Possible cause: An operation mode with validation is set, but the vendor ID or the device ID in the port configuration is "0". The connected device can not be identified and is thus not parameterizable.
<b>IO-Link master/device diagnostics</b>	
PDINV	Process input data invalid The IO-Link master or the IO-Link device report invalid process input data. The connected device is not in status "operate", which means, it is not ready for operation. Possible cause: <ul style="list-style-type: none"> <li>■ The connected device does not match the configured one, additional diagnostic message <b>Wrong or missing device</b>.</li> <li>■ <b>Process input data invalid</b> diagnosis because the process value cannot be measured (depends on the IO-Link device).</li> </ul>
<b>IO-Link device diagnostics</b>	
	The IO-Link device diagnostics depend on the IO-Link device used. Please refer to the documentation for the IO-Link device for more detailed information on the diagnostics.
EVT1	Maintenance events A Maintenance Event in accordance with the IO-Link specification occurred, maintenance necessary.
EVT2	Out-of-specification events An Out-of-Specification Event in accordance with the IO-Link specification occurred.
GENERR	Common error The device sends an error (device status 4, in accordance with IO-Link specification), which is not clearly specified. Read out the device event codes in order to be able to specify the error more precisely.
HWER	Hardware error General hardware error or device malfunction.
LLVU	Lower limit value underrun The process value lies under the parameterized measurement range or the chosen measurement range has been chosen too high.
OLV	Overload The connected device detected an overload.
OTMP	Over temperature A temperature diagnosis is available on the connected device.
PRMERR	Parameterization error The connected device reports a parameterization error (loss of parameters, no parameter initialization, etc.).

<b>Bit</b>	<b>Meaning</b>
ULVE	Upper limit value exceeded The process value exceeds the parameterized measurement range or the chosen measurement range has been chosen too low.
VLOW	Undervoltage One of the voltages at the connected device is below the defined range
VHIGH	Overvoltage One of the voltages at the connected device exceeds the defined range

## 24.5 IO-Link functions for acyclic communication

The acyclic access to the data of IO-Link devices is realized via IO-Link CALLs. In this context, a distinction must be made between data records of the IO-Link master (IOLM) and data records of connected IO-Link devices (IOLD).

The addressing of the IO-Link CALL defines which device is addressed via the CALL:

Addressing is done via the Entity\_Port:

- Entity\_Port 0 = IO-Link master module (IOLM)
- Entity\_Port 1 = IO-Link device at IO-Link port 1
- Entity\_Port 2 = IO-Link device at IO-Link port 2

### 24.5.1 Port functions for Port 0 (IO-Link Master)

IO-Link-Index (port function invocation)

The access to the IO-Link master functionalities (port 0) is done via index 65535:

Subindex 64: Master Port Validation Configuration

The object writes a specific configuration of the devices which have to be connected to the IO-Link port to the master. The master stores the data for the The IO-Link device expected at the port and then accepts only one device at the port with exactly matching data (vendor ID, device ID and serial number).

The Master Port Validation Configuration is only useful in combination with an operation mode with validation (**IO-Link with family compatible device, IO-Link with compatible device, IO-Link with identical device.**)

Entity_Port	IO-Link sub index	Read/write	Length
0	64	Write	Max. 72 byte

Structure of the command IOL\_Port\_Config:

	Content	Size	Format	Comment
IOL1	VENDOR_ID	2 byte	Unsigned 16	
	DEVICE_ID	4 byte	Unsigned 32	
	FUNCTION_ID	2 byte	Unsigned 16	Value: 0
	SERIAL_NUMBER	16 byte	String	
IOL2	VENDOR_ID	2 byte	Unsigned 16	
	DEVICE_ID	4 byte	Unsigned 32	
	FUNCTION_ID	2 byte	Unsigned 16	Value: 0
	SERIAL_NUMBER	16 byte	String	



Subindex 65: IO-Link Events

The object reads IO-Link Event diagnostics.

Entity_Port	IO-Link sub index	Read/write	Length
0	65	Read	255 byte



**NOTE**

Only "appears" (coming diagnostics) and "Single Shot Events" are shown, as long as they are pending.

**Structure of the read data:**

- Byte 0 contains 2 bit per IO-Link port which show, if the process data of the connected device are valid or not.
- 4 byte per diagnostic event, which assign and specify the diagnostics more precisely. A maximum of 14 Events per IO-Link port are shown.

Byte no.	Bit no.								Description	
	7	6	5	4	3	2	1	0		
0								x	PD_Valid Input Port 1	
								x	PD_Valid Output Port 1	
							x		PD_Valid Input Port 2	
						x			PD_Valid Output Port 2	
								-	Reserved	
1	reserved									
2	Qualifier									Defines the type of the event (Warning, Notification, Single Shot Event, etc.) in accordance with IO-Link specification „IO-Link Interface and System“.
3	Port									IO-Link port which sends an event
4	Event Code high byte									High or- low byte of the error code sent
5	Event Code low byte									
...										...
223	Qualifier									See byte 2...5
224	Port									
225	Event Code high byte									
226	Event Code low byte									

### Subindex 66: Set Default Parameterization

Writing this object sets the IO-Link master back to factory settings. Any parameter setting and configuration is overwritten. The data storage buffer is deleted as well.

Entity_Port	IO-Link sub index	Read/write	Length
0	66	Write	4 byte

#### Structure of the reset command:

Byte 3	Byte 2	Byte 1	Byte 0
0xEF	0xBE	0xAD	0xDE

### Subindex 67: Teach Mode

The master reads all data (device ID, vendor ID, serial number, etc.) from the connected device and saves them. All all previously saved device data are overwritten.

Entity_Port	IO-Link sub index	Read/write	Length
0	67	Write	1 byte

#### Structure of the Teach command:

Byte 0	
0x00	Teach all ports
0x01	Teach port 1
0x02	Teach port 2
0x03...0xFF	Reserved

### Subindex 68: Master Port Scan Configuration

The object reads the configuration of the IO-Link devices connected to the IO-Link master.

28 byte are returned per IO-Link port.

Entity_Port	IO-Link sub index	Read/write	Length
0	68	Read	Max. 120 byte

#### Structure of the response telegram:

IO-Link port	Content	Length	Format	Description
Port 1	Vendor ID	2 byte	UINT16	Vendor ID of the connected device
	Device ID	4 byte	UINT32	Device ID of the connected device
	Function ID	2 byte	UINT16	Reserved
	Serial Number	16 byte	UINT8	Serial number of the connected device
	COM_Revision	1 byte	UINT8	IO-Link version
	Proc_In_Length	1 byte	UINT8	Process input data length of the connected device
	Proc_Out_Length	1 byte	UINT8	Process output data length of the connected device
	Cycle time	1 byte	UINT8	Cycle time of the connected device
Port 2	Structure similar to port 1			

## Subindex 69: Extended Port Diagnostics

The object reads the Extended Port Diagnostics.

Entity_Port	IO-Link sub index	Read/write	Length
0	68	Read	Max. 8 byte

### Structure of the Extended Port Diagnostics:

Byte no.	Bit no.							
	7	6	5	4	3	2	1	0
0	NO_SIO	TCYC	-	-	DS_F	NO_DS	-	-
1	-	WD	MD	PDI_H	-	-	NO_PD	-
2	-	-	-	-	-	-	-	-
3	Device status according to IO-Link specification							

Diagnostic bit	Meaning
NO_DS	The parameterized port mode does not support data storage. Remedy: <ul style="list-style-type: none"> <li>■ Change the parameterization of the port.</li> </ul>
DS_F	Error in the data storage, synchronization not possible Possible causes: <ul style="list-style-type: none"> <li>■ Connected device does not support data storage</li> <li>■ Overflow of the data storage buffer</li> </ul> Remedy: <ul style="list-style-type: none"> <li>▶ Connect a device that supports data storage.</li> <li>▶ Clear the data storage buffer.</li> <li>▶ Deactivate the data storage.</li> </ul>
TCYC	The device does not support the cycle time parameterized in the master. Remedy: <ul style="list-style-type: none"> <li>▶ Increase the cycle time set in the master.</li> </ul>
NO_SIO	The device does not support the standard DI (SIO) mode. Remedy: <ul style="list-style-type: none"> <li>▶ Select the IO-Link mode for this port.</li> </ul>
NO_PD	No process data available The connected device is not ready for operation. Remedy: <ul style="list-style-type: none"> <li>▶ Check the configuration.</li> </ul>
PDI_E	The connected device reports invalid process data in accordance with IO-Link specification V1.0.
PDI_H	The connected device reports invalid process data in accordance with IO-Link specification V1.1.
MD	Missing device, no IO-Link device detected. Remedy: <ul style="list-style-type: none"> <li>■ Check the IO-Link cable.</li> <li>■ Change the device.</li> </ul>
WD	Wrong device detected: one or more parameters of the connected device (vendor ID, device ID, serial number) does not/do not match the data which are stored in the master for this device. Remedy: <ul style="list-style-type: none"> <li>■ Change the device.</li> <li>■ Adapt the master parameterization</li> </ul>

Device Status

<b>Value</b>	<b>Meaning</b>
0	Device works correctly
1	Maintenance Event
2	Out-of-Specification Event
3	Functional check
4	Error
5...255	Reserved

## 24.6 Using the data storage mode

### Data storage mode



#### NOTE

Data storage mode is only available for devices complying with the IO-Link specification V1.1.

In the IO-Link master, the data storage mode can be set using the parameter "data storage mode".

- 00 = activated
- 01 = overwrite
- 10 = read in
- 11 = deactivated, clear




Fig. 92: Data storage mode – general principle, Para. IOLD = parameters of the IO-Link device

A change of parameters in the device is indicated by the status of the DS\_UPLOAD\_FLAG bit:

- 0 = no changes in the device's parameter set
- 1 = changes in the device's parameter set (e. g. via DTM, at the device, etc.)

#### 24.6.1 Parameter "Data storage mode" = activated

The synchronization of the parameter sets is bidirectional.

The actual data set (master or device) is valid:

The following applies:

- The data set in the device is actual, if DS\_UPLOAD\_FLAG = 1.
- The data set in the Master is actual, if DS\_UPLOAD\_FLAG = 0.

Use Case 1: Parameterizing the Device using e.g. a DTM

- ✓ The IO-Link device is already installed in the system and connected to the master.
- ▶ Parameterizing the device via DTM.
- ⇒ DS\_UPLOAD\_FLAG = 1, parameter set in the device changed.
- ⇒ The parameter data are transferred from the new IO-Link device to the IO-Link master.




Fig. 93: Data storage mode activated – parameter set in the device changed

Use case 2: replace a defective device with a device in the delivery state.

- ✓ The **new** IO-Link device has **not** been connected to the master before.
- ▶ The parameters of the new device remain unchanged, DS\_UPLOAD\_FLAG = 0.
- ⇒ The parameter data of the defective device are transferred from the IO-Link master to the new IO-Link device.




Fig. 94: Data storage mode activated – parameter set in the device unchanged

Use case 3: replace a defective device with a device with unknown (changed) parameters

- ✓ The **new** IO-Link device has **not** been connected to the master before.
- ▶ The parameters of the new device remain unchanged, DS\_UPLOAD\_FLAG = 1.
- ⇒ The parameter data are transferred from the new IO-Link device to the IO-Link master.




Fig. 95: Data storage mode activated – parameter set in the device changed



**NOTE**

If device replacement is necessary when data storage is activated, an IO-Link replacement device with unknown parameter data should be reset to its factory settings before connection to the IO-Link master.

Turck IO-Link devices can be reset to factory settings via a system command using a generic IO-Link DTM and the device specific IODD. For the reset of third party devices, please read the corresponding manufacturer documentation.

24.6.2 Parameter "Data storage mode" = read in

- The data set in the device is **always** the reference data set.
- The synchronization of the parameter sets is unidirectional towards to the master.
- The status of the DS\_UPLOAD\_FLAG is ignored.




Fig. 96: Data storage mode = read in – parameter set in the device changed

#### 24.6.3 Parameter "Data storage mode" = overwrite

- The data set in the master is **always** the reference data set.
- The synchronization of the parameter sets is unidirectional towards to the device.
- The status of the DS\_UPLOAD\_FLAG is ignored.




Fig. 97: Data storage mode = overwrite – parameter set in the master changed

#### 24.6.4 Parameter "Data storage mode" = deactivated, clear

- The data set in the master is deleted.
- The synchronization of parameter sets is deactivated.



Fig. 98: Data storage mode deactivated – no synchronization



## 25 Troubleshooting

### 25.1 Eliminating parameterization errors

#### DXP channels


Error	Possible causes:	Remedy
DXP output does not switch	The output is deactivated per default.	▶ Enable the output function via parameter <b>Activate output</b> (DXP_EN_DO =1).

#### IO-Link channels

LED behavior	Diagnostics	Possible causes:	Remedy
LED MS and IOL red blinking	Data storage error	IO-Link device according to IO-Link V1.0 connected IO-Link devices in accordance with IO-Link specification V1.0 do not support data storage.	▶ Set parameter Data storage mode to <b>deactivated, clear</b> . ⇒ Data storage remain deactivated.
		The data storage buffer contains data of another device.	▶ Set parameter Data storage mode to <b>deactivated, clear</b> . ▶ Re-activate the data storage if necessary.
	Wrong or missing device	The connected device does not match the configured one (wrong vendor ID, device ID etc.)	▶ Adapt the parameterization of the IO-Link port (vendor ID, device ID, etc.) at the master. The parameterization can be done manually via DTM, the web server or similar or by teaching the master using the IO-Link-Call (port 0 function, sub index 67: Teach mode).
Process input data invalid	Certain IO-Link devices send a <b>process input data invalid</b> diagnosis if the process value cannot be measured.	▶ Deactivate the sending of the diagnosis for the IO-Link port with the parameter <b>Process input data invalid</b> → <b>No diagnostic generated</b> .	

## 26 Technical Data – IO-Link Channels

The first section of the operating instructions contains the general technical data of the device [► 95].

<b>Technical data</b>	
<b>Supply</b>	
Permissible range	20.4...28.8 VDC (acc. to IO-Link specification)
Operating current	< 120 mA
Power supply of the IO-Link ports	
IO-Link port 1 at C6 or X6	VAUX1, max. 2 A
IO-Link port 2 at C7 or X7	FSO1, max. 2 A
Derating	
Potential isolation	≥ 500 V (V2 to Ethernet and V1)
<b>IO-Link ports</b>	
Ports	4
IO-Link specification	V1.0, V1.1 according to IEC 61131-9
Outputs IO-Link port type	Class A and Class B
Frame type	Supports all frame types
Process data for IO-Link device	
■ Input data	Max. 32 bytes per channel
■ Output data	Max. 32 bytes per channel
Transmission rate	4.8 kbps (COM 1) 38.4 kbps (COM 2) 230.4 kbps (COM 3)
Transmission cable	Length: max. 20 m, standard cables, 3- or 4-wire (depending on the application), unshielded

## 27 Appendix: Approvals and Markings

Approvals	Marking according to ATEX directive	EN 60079-0/-7/-31
ATEX approval no.: TÜV 20 ATEX 264795 X	⊕ II 3 G ⊕ II 3 D	Ex ec IIC T4 Gc Ex tc IIIC T115 °C Dc
IECEX approval no.: IECEX TUN 20.0010X		Ex ec IIC T4 Gc Ex tc IIIC T115 °C Dc

Ambient temperature  $T_{amb.}$ : -25 °C...+60 °C

Type designation	TB...-L...-FDIO1-2IOL
Power supply	24 VDC ±10 %
Input current $I_{max}$	9 A (total per module)
Output current $I_{max}$	1,5 A (per output)

## 28 Turck Subsidiaries - Contact Information

<b>Germany</b>	Hans Turck GmbH & Co. KG Witzlebenstraße 7, 45472 Mülheim an der Ruhr <a href="http://www.turck.de">www.turck.de</a>
<b>Australia</b>	Turck Australia Pty Ltd Building 4, 19-25 Duerdin Street, Notting Hill, 3168 Victoria <a href="http://www.turck.com.au">www.turck.com.au</a>
<b>Belgium</b>	TURCK MULTIPROX Lion d'Orweg 12, B-9300 Aalst <a href="http://www.multiprox.be">www.multiprox.be</a>
<b>Brazil</b>	Turck do Brasil Automação Ltda. Rua Anjo Custódio Nr. 42, Jardim Anália Franco, CEP 03358-040 São Paulo <a href="http://www.turck.com.br">www.turck.com.br</a>
<b>China</b>	Turck (Tianjin) Sensor Co. Ltd. 18,4th Xinghuazhi Road, Xiqing Economic Development Area, 300381 Tianjin <a href="http://www.turck.com.cn">www.turck.com.cn</a>
<b>France</b>	TURCK BANNER S.A.S. 11 rue de Courtalin Bat C, Magny Le Hongre, F-77703 MARNE LA VALLEE Cedex 4 <a href="http://www.turckbanner.fr">www.turckbanner.fr</a>
<b>Great Britain</b>	TURCK BANNER LIMITED Blenheim House, Hurricane Way, GB-SS11 8YT Wickford, Essex <a href="http://www.turckbanner.co.uk">www.turckbanner.co.uk</a>
<b>India</b>	TURCK India Automation Pvt. Ltd. 401-403 Aurum Avenue, Survey. No 109 /4, Near Cummins Complex, Baner-Balewadi Link Rd., 411045 Pune - Maharashtra <a href="http://www.turck.co.in">www.turck.co.in</a>
<b>Italy</b>	TURCK BANNER S.R.L. Via San Domenico 5, IT-20008 Bareggio (MI) <a href="http://www.turckbanner.it">www.turckbanner.it</a>
<b>Japan</b>	TURCK Japan Corporation Syuuhou Bldg. 6F, 2-13-12, Kanda-Sudacho, Chiyoda-ku, 101-0041 Tokyo <a href="http://www.turck.jp">www.turck.jp</a>
<b>Canada</b>	Turck Canada Inc. 140 Duffield Drive, CDN-Markham, Ontario L6G 1B5 <a href="http://www.turck.ca">www.turck.ca</a>
<b>Korea</b>	Turck Korea Co, Ltd. B-509 Gwangmyeong Technopark, 60 Haan-ro, Gwangmyeong-si, 14322 Gyeonggi-Do <a href="http://www.turck.kr">www.turck.kr</a>
<b>Malaysia</b>	Turck Banner Malaysia Sdn Bhd Unit A-23A-08, Tower A, Pinnacle Petaling Jaya, Jalan Utara C, 46200 Petaling Jaya Selangor <a href="http://www.turckbanner.my">www.turckbanner.my</a>

<b>Mexico</b>	Turck Comercial, S. de RL de CV Blvd. Campestre No. 100, Parque Industrial SERVER, C.P. 25350 Arteaga, Coahuila <a href="http://www.turck.com.mx">www.turck.com.mx</a>
<b>Netherlands</b>	Turck B. V. Ruiterlaan 7, NL-8019 BN Zwolle <a href="http://www.turck.nl">www.turck.nl</a>
<b>Austria</b>	Turck GmbH Graumanngasse 7/A5-1, A-1150 Wien <a href="http://www.turck.at">www.turck.at</a>
<b>Poland</b>	TURCK sp.z.o.o. Wroclawska 115, PL-45-836 Opole <a href="http://www.turck.pl">www.turck.pl</a>
<b>Romania</b>	Turck Automation Romania SRL Str. Siriului nr. 6-8, Sector 1, RO-014354 Bucuresti <a href="http://www.turck.ro">www.turck.ro</a>
<b>Russian Federation</b>	TURCK RUS OOO 2-nd Pryadilnaya Street, 1, 105037 Moscow <a href="http://www.turck.ru">www.turck.ru</a>
<b>Sweden</b>	Turck Sweden Office Fabriksstråket 9, 433 76 Jonsered <a href="http://www.turck.se">www.turck.se</a>
<b>Singapore</b>	TURCK BANNER Singapore Pte. Ltd. 25 International Business Park, #04-75/77 (West Wing) German Centre, 609916 Singapore <a href="http://www.turckbanner.sg">www.turckbanner.sg</a>
<b>South Africa</b>	Turck Banner (Pty) Ltd Boeing Road East, Bedfordview, ZA-2007 Johannesburg <a href="http://www.turckbanner.co.za">www.turckbanner.co.za</a>
<b>Czech Republic</b>	TURCK s.r.o. Na Brne 2065, CZ-500 06 Hradec Králové <a href="http://www.turck.cz">www.turck.cz</a>
<b>Turkey</b>	Turck Otomasyon Ticaret Limited Sirketi Inönü mah. Kayisdagi c., Yesil Konak Evleri No: 178, A Blok D:4, 34755 Kadiköy/ Istanbul <a href="http://www.turck.com.tr">www.turck.com.tr</a>
<b>Hungary</b>	TURCK Hungary kft. Árpád fejedelem útja 26-28., Óbuda Gate, 2. em., H-1023 Budapest <a href="http://www.turck.hu">www.turck.hu</a>
<b>USA</b>	Turck Inc. 3000 Campus Drive, USA-MN 55441 Minneapolis <a href="http://www.turck.us">www.turck.us</a>

# TURCK

Over 30 subsidiaries and over  
60 representations worldwide!

100000718 | 2021/11



[www.turck.com](http://www.turck.com)