

Pick-to-Light **Placement Sensor Capacitive Sensor** K70APT2GREQ



 M12 x Job light Mispich Actuati Operat
Mispick Actuati Operat
Actuati
Operat
Operat
· ·
PNP s\
NO cor
— Capaci
tion
High in
ing, det
nants
$ = \Psi $
— Functiona
—— The K70 p
many mou
application
nal lights a
dome (dep
sistor outp
tem contro
cial task se
-



- tion class IP65
- 1 male connector, 4-pin
- ht: green
- k: red
- ion: not signalled
- ting voltage 12...30 VDC
- witching
- ntact
- itive sensor of the second genera-
- nmunity to false actuation by splashtergents, oils and other contami-

iagram



al principle

bick-and-place sensor is suitable for unting and component placement ns. The green work light or other sigare reflected perfectly by the entire pending on the version). The tranout can be easily connected to a sysol, which is programmed for a speequence. The work light of the sensor is located in or next to every bin at the operator's workstation and indicates: 1. The bins with the components to be picked up for a particular work step and 2. the sequence in which the components have to be picked up.



If the operator removes a part from the bin, the K50 detects the hand in the bin and sends a signal to the control unit. The system then checks if the correct component has been picked up and – depending on the configuration – switches the corresponding work light off and the next one on, according to the assembly sequence. The work sequence control leads to increased efficiency, improved quality control and reduces rework and testing expenses.

The term **work light** therefore refers to the visual indicator of the bin from which a part should be removed next. The **actuation in-dicator** confirms the removal with a different color. The **mispick indicator** illuminates if a bin was reached into when the work light was not set.