


NI10-EM18-Y1X-H1141 Inductive Sensor




Technical data

Туре	NI10-EM18-Y1X-H1141	
ID	1006261	
General data		
Rated switching distance	10 mm	
Mounting conditions	Non-flush	
Secured operating distance	≤ (0.81 × Sn) mm	
Correction factors	St37 = 1; Al = 0.3; stainless steel = 0.7; Ms = 0.4	
Repeat accuracy	≤ 2 % of full scale	
Temperature drift	≤ ±10 %	
Hysteresis	110 %	
Electrical data		
Output function	2-wire, NAMUR	
Switching frequency	0.5 kHz	
Voltage	Nom. 8.2 VDC	
Non-actuated current consumption	≥ 2.1 mA	
Actuated current consumption	≤ 1.2 mA	
Approval acc. to	KEMA 02 ATEX 1090X	
Internal capacitance (C _i)/inductance (L _i)	150 nF/150 μH	
Device marking	EX II 1 G Ex ia IIC T6 Ga/II 1 D Ex ia IIIC T135 °C Da	
	(max. U _i = 20 V, I _i = 20 mA, P _i = 200 mW)	
Mechanical data		
Design	Threaded barrel, M18 x 1	
Dimensions	52 mm	
Housing material	Stainless steel, 1.4301 (AISI 304)	
Active area material	Plastic, PBT	
Max. tightening torque of housing nut	25 Nm	

Features

- ■Threaded barrel, M18 x 1
- Stainless steel, 1.4301
- ■DC 2-wire, nom. 8.2 VDC
- Output acc. to EN 60947-5-6 (NAMUR)
- ■M12 × 1 connector
- ■ATEX category II 1 G, Ex zone 0
- ■ATEX category II 1 D, Ex zone 20
- SIL2 (Low Demand Mode) acc. to IEC 61508, PL c acc. to ISO 13849-1 with HFT0
- SIL3 (All Demand Mode) acc. to IEC 61508, PL e acc. to ISO 13849-1 with redundant configuration HFT1

Wiring diagram



Functional principle

Inductive sensors detect metal objects contactless and wear-free. For this, they use a high-frequency electromagnetic AC field that interacts with the target. Inductive sensors generate this field via an RLC circuit with a ferrite coil.




Technical data

Electrical connection	Connector, M12 × 1	
Environmental conditions		
Ambient temperature	-25+70 °C	
Vibration resistance	55 Hz (1 mm)	
Shock resistance	30 g (11 ms)	
Protection class	IP67	
MTTF	6198 years acc. to SN 29500 (Ed. 99) 40 °C	
Switching state	LED, Yellow	


Mounting instructions

Mounting instructions/Description




Distance D	3 x B
Distance W	3 x Sn
Distance T	3 x B
Distance S	1.5 x B
Distance G	6 x Sn
Distance N	2 x Sn
Diameter active area B	Ø 18 mm

Accessories



6945004 Mounting bracket for threaded barrel sensors; material: Stainless steel A2 1.4301 (AISI 304)




BSS-18

Mounting clamp for smooth and threaded barrel sensors; material: Polypropylene

6901320



QM-18 6945102




Quick-mount bracket with dead-stop; material: Chrome-plated brass. Male thread M24 × 1.5. Note: The switching distance of the proximity switches may change when using quick-mount brackets.

Accessories

Dimension drawing	Туре	ID	
M12×1 e 15	RKC4.221T-2/TEB	6628420	Connection cable, M12 female connector, straight, 2-pin, cable length: 2 m, jacket material: PVC, blue; cULus approval
015 M12x1 26.5 32	WKC4.221T-2/TEB	6628427	Connection cable, M12 female connector, angled, 2-pin, cable length: 2 m, jacket material: PVC, blue; cULus approval

Accessories





Instructions for use

Intended use	This device fulfills Directive 2014/34/EC and is suited for use in explosion-hazardous areas according to EN 60079-0:2018 and EN 60079-11:2012.It is also suitable for use in safety-related systems, including SIL2 (IEC 61508) and PL c (ISO 13849-1) with HFT0 and SIL3 (IEC 61508) and PL e (ISO 13849-1) with redundant configuration HFT1In order to ensure that the device is operated as intended, the national regulations and directives must be observed.
For use in explosion hazardous areas conform to classification	II 1 G and II 1 D (Group II, Category 1 G, electrical equipment for gaseous atmospheres and category 1 D, electrical equipment for dust atmospheres).
Marking (see device or technical data sheet)	
Local admissible ambient temperature	-25+70 °C
Installation/Commissioning	These devices may only be installed, connected and operated by trained and qualified staff. Qualified staff must have knowledge of protection classes, directives and regulations concerning electrical equipment designed for use in explosion hazardous areas. Please verify that the classification and the marking on the device comply with the actual application conditions.
	This device is only suited for connection to approved Exi circuits according to EN 60079-0 and EN 60079-11. Please observe the maximum admissible electrical values. After connection to other circuits the sensor may no longer be used in Exi installations. When interconnected to (associated) electrical equipment, it is required to perform the "Proof of intrinsic safety" (EN60079-14). Attention! When used in safety systems, all content of the security manual must be observed.
Installation and mounting instructions	Avoid static charging of cables and plastic devices. Please only clean the device with a damp cloth. Do not install the device in a dust flow and avoid build-up of dust deposits on the device. If the devices and the cable could be subject to mechanical damage, they must be protected accordingly. They must also be shielded against strong electro-magnetic fields. The pin configuration and the electrical specifications can be taken from the device marking or the technical data sheet.
Service/Maintenance	Repairs are not possible. The approval expires if the device is repaired or modified by a person other than the manufacturer. The most important data from the approval are listed.